

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION  
OIL CONSERVATION DIVISION  
SANTA FE

MAY 26 1981

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
L-5898	

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry Hole		7. Unit Agreement Name
2. Name of Operator Cities Service Company		8. Farm or Lease Name State DP
3. Address of Operator P.O. Box 1919 - Midland, Texas 79702		9. Well No. 1
4. Location of Well UNIT LETTER G 1980 FEET FROM THE North LINE AND 1980 FEET FROM THE East LINE, SECTION 16 TOWNSHIP 17N RANGE 30E NMPM.		10. Field and Pool, or Wildcat Bravo Dome Area
15. Elevation (Show whether DF, RT, GR, etc.) 4331' GR		12. County Harding

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

T.D. 2400' Shale & Granite. Plugged & abandoned. This well was plugged and abandoned in the following manner:

1. MIRU pulling unit and set a CIBP @ 600' and dumped 10 sacks of Class H cement on top @ 600 - 550'.
2. Set a 5 sack cement surface plug @ 40 - bottom of cellar.
3. Filled cellar and set a 4" dry hole marker to designate a plugged and abandoned location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED E. J. J. J. TITLE Region Opr. Mgr. - Prod. DATE 5-21-81  
APPROVED BY Carl J. J. TITLE SENIOR PETROLEUM GEOLOGIST DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY: