

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

OIL CONSERVATION DIVISION
SANTA FE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

MAY 26 1981

11. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
12. State Oil & Gas Lease No.	
L-5898	
7. Unit Agreement Name	
8. Farm or Lease Name	
State DP	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
Bravo Dome Area	
15. Elevation (Show whether DF, RT, GR, etc.)	
4331' GR	
12. County	
Harding	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry Hole
2. Name of Operator Cities Service Company
3. Address of Operator P.O. Box 1919 - Midland, Texas 79702
4. Location of Well UNIT LETTER G, 1980 FEET FROM THE North LINE AND 1980 FEET FROM THE East LINE, SECTION 16 TOWNSHIP 17N RANGE 30E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4331' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

T.D. 2400' Shale & Granite. Plugged & abandoned. This well was plugged and abandoned in the following manner:

1. MIRU pulling unit and set a CIBP @ 600' and dumped 10 sacks of Class H cement on top @ 600 - 550'.
2. Set a 5 sack cement surface plug @ 40 - bottom of cellar.
3. Filled cellar and set a 4" dry hole marker to designate a plugged and abandoned location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED E. Spiller TITLE Region Opr. Mgr. - Prod. DATE 5-21-81

APPROVED BY Carl Wong TITLE SENIOR PETROLEUM GEOLOGIST DATE _____

CONDITIONS OF APPROVAL, IF ANY: