

10/4/76

Memo

From

CARL ULVOG

SENIOR

PETROLEUM GEOLOGIST

To

Bill Brooks:

According to the reports you have sent us on the Mass well, your 7" csg. is set at 1019'; the Dakota was topped at 1252'; and T.D. is at 1272'.

To confirm our telephone conversation of this morning, it looks as if you have got about 20' of Dakota open. To cover this section with cement you should put at least 11 sacks of cement on the bottom of the hole. (1 sack would get about 2.0' to 2.2' linear feet of hole.) To get a plug at bottom of 7" csg., try to get at least 6' of hole plus 10' of csg. with a 5 sack plug. A 3 sack plug at surface, with the marker set in, ought to finish the job.

C.U.