N.M. Oil Cons. DIV-Dist. 2

Form 3160-5 (June 1990)

united states 1301 W. Grand Avenue DEPARTMENT OF THE INTERIOR SIA, NIVI 88210 BUREAU OF LAND MANAGEMENT

FORM APPROVED Budget Bureau No. 1004-0135 Expires: March 31, 1993

5.	Lease	Designati	on and	Serial	No.
		NM	2765	0	

6 If Indian Allottee or Tribe Name

SUNDRY NOTICES AND REPORTS ON WELLS
Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
LISS "APPLICATION FOR DEPMIT" for such proposals

Do not		ill or to deepen or reentry to a different reservoir. DR PERMIT-" for such proposals	or in motion, runction of the industry		
	SUBMIT	7. If Unit or CA, Agreement Designation			
1. Type of Well Oil Gas Well Other 2. Name of Operator		RECEIVED	8. Well Name and No. Grace CG Federal #1		
Claco Oil Company		SEP 1 7 2004	9. API Well No.		
13 H	ss and Telephone No. avenhill Rd. Artesia, NM 88210 (505) 45		3001525603 10. Field and Pool, or Exploratory Area		
	on of Well (Footage, Sec., T., R., M., or Survey De 5, T26S,R30E, Unit leatter J	Ross Draw Del.			
	, , , , , , , , , , , , , , , , , , , ,	11. County or Parish, State			
			Eddy NM		
12.	CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA				
	TYPE OF SUBMISSION	TYPE OF ACTION			
	Notice of Intent		Change of Plans		
		Recompletion	New Construction		
	Subsequent Report	Plugging Back	Non-Routine Fracturing		
		Casing Repair	Water Shut-Off		
	Final Abandonment Notice	Altering Casing	Conversion to Injection		
		Other	Dispose Water		
			(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)		

13. Describe Proposed or Completed Operations (Clearly state all pertinet details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markders and zones pertinent to this work.)*

Notify BLM 24 hrs before starting Plugging

- 1. POH w/ rods & tubing set 5 1/2 CIBP @ 5720' w/ 35' cmt on top
- 2. RIH circulate well W/ mud Spot 100' plug @ 5350 (DV tool @ 5293')
- 3. Pull strech on 5 1/2 if free below 33650cut & pull if not spot 100' Plug @ 3650 (8 5/8 shoe @ 3555) woc tag
- 4. Spot 100' plug 50' in & 50' out cut woc tag 5. Spot 100' plug @ 970' (13 3/8 shoe @ 919') woc tag
- 8. Spot cmt. 60' to surface
- 9. Cut off well head install dry hole marker

14. I hereby certify that the foregoing is true and correct Signed Assem Bayes Title	A22 4 /2	Date 9/13/04
(This space for Federal or State office use)	PETROLEUM ENGINEER	Date SEP 1 5 2004
Approved by(OHIG. SGD.) ALBRIS C. SMOBODAttle _Conditions of approval, if any:		Date