

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT  
1601 W. Grand Avenue  
Alamosa, NM 88210

FORM APPROVED  
OMB NO. 1004-0137  
Expires March 31, 2007

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

SUBMIT IN TRIPLICATE - Other instructions on reverse side

RECEIVED

JAN 24 2005

1. Type of Well  
☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator  
EOG Resources Inc.

3a. Address  
P.O. Box 2267 Midland, Texas 79702

3b. Phone No. (include area code)  
432 686 3689

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)  
1980' FWL & 660' FSL  
Sec 4, T18S, R30E

5. Lease Serial No.

NM 01159

6. If Indian, Allottee or Tribe Name

7. If Unit or CA/Agreement, Name and/or No.

8. Well Name and No.

Holly 4 Fed Com 1

9. API Well No.

30-015-24245

10. Field and Pool, or Exploratory Area  
Undesignated

11. County or Parish, State

Eddy

Nm

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Acidize ☐ Deepen ☐ Production (Start/Resume) ☐ Water Shut-Off  
☐ Alter Casing ☐ Fracture Treat ☐ Reclamation ☐ Well Integrity  
☐ Casing Repair ☐ New Construction ☐ Recomplete ☐ Other  
☐ Change Plans ☐ Plug and Abandon ☒ Temporarily Abandon  
☐ Convert to Injection ☐ Plug Back ☐ Water Disposal

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleate horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleation in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the final site is ready for final inspection.)

Procedure to Temporarily Abandon:

RIH with CIBP and set @ 10375' with 35' cement on top or  
RIH with tubing and spot 30 sx of cement from 10375' to 10275'.

RIH with tubing and spot 30 sx of cement from 8464' to 8364'. (Top of Wolfcamp)

RIH with tubing and spot 50 sx of cement from 6645' to 6845'. (Top of Bone Spring)

Attempt to recover 6500' of 5 1/2" casing. Spot plug 50' in & 50' out of stub & tag.

RIH with tubing and spot 20 sx of cement from 4495' to 4595'. (Top of Glorieta) tag

RIH with CIBP and set at 3223' with 35' of cement on top. (Top of San Andres)

Pressure test 8 5/8" casing to 500 psi for 30 minutes and chart.

Hole will be displaced with 9.5 ppg mud laden fluid.

\* W/ changes

14. I hereby certify that the foregoing is true and correct  
Name (Printed/Typed)

Stan Wagner

Title

Regulatory Analyst

Date 12/14/04

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

/s/ Joe G. Lara

Title

Office

Date

JAN 20 2005

\* Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Title 18 U.S.C. Section 1001, and Title 43 U.S.C. Section 1212, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.