OCD-ARTESIA

Form 3160-5 (August 2007)

UNITED STATES DEPARTMENT OF THE INTERIOR **BUREAU OF LAND MANAGEMENT**

SUNDRY NOTICES AND REPORTS ON WELLS

FORM APPROVED
OMB No 1004-0137
Expires: July 31, 2010

Lease Serial No.

LC-070937

6. If Indian, Allottce or Tribe Name Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals. 7. If Unit of CA/Agreement, Name and/or No SUBMIT IN TRIPLICATE - Other instructions on page 2. 1. Type of Well 8. Well Name and No West Red Lake Unit #45 Oil Well Gas Well Other 2 Name of Operator 9. API Well No Lime Rock Resources II-A, L.P. 30-015-28445 10. Field and Pool or Exploratory Area 3a. Address 3b. Phone No. (include area code) 1111 Bagby Street Suite 4600, Houston, Tx 77002 Red Lake (Q-GB-SA) 575-623-8424 4. Location of Well (Footage, Sec., T.,R.,M., or Survey Description) 11. Country or Parish, State Sec 4 - T18S-R27E 990' FSL & 330' FWL Eddy County, NM 12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT OR OTHER DATA TYPE OF SUBMISSION TYPE OF ACTION Acidize Deepen Production (Start/Resume) Water Shut-Off Notice of Intent Alter Casing Fracture Treat **▼** Reclamation Well Integrity New Construction Other Casing Repair Recomplete ✓ Subsequent Report Change Plans Plug and Abandon Temporarily Abandon Final Abandonment Notice Convert to Injection Plug Back Water Disposal 13 Describe Proposed or Completed Operation: Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.) Leveled area. Spread 4 bales of hay over entire area. Brought in 12" good top soil & flipped top with track hoe. Leveled area with disc. Applied jump start nutrient pack (R & A Technology). ACCEPTED FOR RECORD Bermed site and watered area. Continued watering area for one (1) month. All work has been completed. MAR 2 0 2012 MAR 1 7 2012 Accepted for record NMOCO ACTOR AU OF LAND MANAGEMENT CARLSBAD FIELD OFFICE 14. I hereby certify that the foregoing is true and correct. Name (Printed/Typed) Michael Barrett Production Supervisor Date 10/21/2011 Signature THIS SPACE FOR FEDERAL OR STATE OFFICE USE Approved by Date Title Conditions of approval, if any, are attached Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would Office entitle the applicant to conduct operations thereon

Title 18 U S.C. Section 1001 and Title 43 U S C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false,

fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2)



September 28, 2011

Attention:

Jerry Smith, Mike Barrett and Steve Hunter, Lime Rock

From:

Rob Johnston, R&A Technology

832-244-3811

Regarding:

Old Drilling Pit Update

During our April 2011 meeting with the Jim Amos and Jenifer VanCuren of the BLM, the work plan for remediating the old drilling pits was presented and accepted. It was agreed that 8 pits would be worked on this year and additional pits would be done in 2012 to help Lime Rock spread the cost of these projects.

The plan was as follows:

- Level the area
- Roll 3-4 round bales of hay over the entire area.
- Bring in 12" of good clay soil
- Spread new soil evenly
- Flip the top 24" using a Track Hoe, creating a 24" growth zone.
- Level the area by disking.
- Apply Jump Start Nutrient Pack
- Add a 3-6" berm wall to hold initial watering over the area.
- Water Weekly for 1 month.

This plan was specifically designed to add good soil and nutrients to the very poor soil, providing a better environment for vegetation. There were no initial samples analysis taken and with plant growth apparent on each site there should be no need for follow-up samples.

This plan has been completed on all 8 pits and plant growth has started and is visible in all 8 pits.

Thanks,

Rob Johnston

Remediation and Applied Technology