'1Submit 3 Copies To Appropriate District	State of]	New Me	xico		Form C-10	03
Office District I	Energy, Minerals	and Natu	ral Resources		March 4, 20)04_
1625 N. French Dr., Hobbs, NM 88240				WELL API NO).	
District II 1301 W. Grand Ave. Artesia NM 88210 OIL CONSERVATION DIVISION			ридеюм	30-015-33974		
1301 W. Glaim Ave., Aleesia, IVM 60210			5. Indicate Typ	e of Lease		
District III 1220 South St. Francis Dr.			STATE			
1000 Rio Brazos Rd., Aztec, NM 87410 District IV Santa Fe, NM 87505			6. State Oil &		\neg	
1220 S. St. Francis Dr., Santa Fe, NM		,		5. Suits 62 65		ĺ
87505						
SUNDRY NOT	ICES AND REPORTS OF	N WELLS		7. Lease Name	or Unit Agreement Name	e
(DO NOT USE THIS FORM FOR PROPO	SALS TO DRILL OR TO DEED	PEN OR PLU	JG BACK TO A	Big Chief Fee		
DIFFERENT RESERVOIR. USE "APPLI	CATION FOR PERMIT" (FOR	M C-101) FO	OR SUCH			
PROPOSALS.)			8. Well Number			
1. Type of Well: Oil Well			#8		[
	Other	; 1L	CLIVED			
2. Name of Operator		ΔΡ	PR 2 9 2005	9. OGRID Nu	mber	
Nadel and Gussman Permian, LLC	·			155615		
3. Address of Operator		Oor	PARTERIA	10. Pool name	or Wildcat	
601 N. Marienfeld Suite 508 Midla	and, Texas 79701			Dublin Ranch;	Morrow)
4. Well Location				<u> </u>		
4. Well Excellen						
Unit Letter O : 99	O' foot from the Court	h lina e	and 1650' 4	eat from the Fact	line	
Oint LetterO99	Oieet from the Souti	ii iiiie a	inu10301	eet mom me rast	mic	
Castian 22		20 E	NMPM	Cour	ter Edder	1
Section 22 To	wnship 22-S Range	20-E			ty Eddy	والتوالية
	11. Elevation (Show wh	netner DK,	KKB, KI, GK, eic.		and presidents	
	3097'					-
Pit or Below-grade Tank Application (Fo	r pit or below-grade tank closi	ires, a form	C-144 must be attache	<u>(1)</u>		
Pit Location: ULO_Sect 22_Twp 22-	SRng 28-E Pit type Rese	rve _Depth	to Groundwater 100'+	Distance from ne	arest fresh water well 1000'+_	_
Distance from nearest surface water 10	00'+ Relow-grade Tank I	ocation UL	Sect	Twp Rng	:	
						l l
	feet trom the					
feet from theline and _		me				
teet from the time and	Text II via de	me				
			-A	Donort on Oth	on Doto	
12. Check	Appropriate Box to In		ature of Notice,	Report or Oth	er Data	
12. Check A	Appropriate Box to In	dicate N	SUE	SEQUENT R	REPORT OF:	
12. Check	Appropriate Box to In	dicate N	ature of Notice, SUE	SEQUENT R	EPORT OF:	
12. Check A	Appropriate Box to In ITENTION TO: PLUG AND ABANDON	dicate N	REMEDIAL WOR	SEQUENT R	REPORT OF: ALTERING CASING	_
12. Check A	Appropriate Box to In ITENTION TO: PLUG AND ABANDON	dicate N	SUE	SEQUENT R	REPORT OF: ALTERING CASING [PLUG AND [
12. Check A NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS	ndicate N	REMEDIAL WOR	SEQUENT R	EPORT OF: ALTERING CASING [PLUG AND [ABANDONMENT	_
12. Check ANOTICE OF IN	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE	ndicate N	REMEDIAL WOR	SEQUENT R	EPORT OF: ALTERING CASING [PLUG AND [ABANDONMENT	_
12. Check A NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS	ndicate N	REMEDIAL WOR	SEQUENT R	EPORT OF: ALTERING CASING [PLUG AND [ABANDONMENT	
12. Check A NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE	adicate N	REMEDIAL WOR COMMENCE DR CASING TEST A CEMENT JOB	SEQUENT R ILLING OPNS.	EPORT OF: ALTERING CASING [PLUG AND [ABANDONMENT	_
12. Check NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER:	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION	dicate N	REMEDIAL WOR COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend	SEQUENT R RK ILLING OPNS. ND MD	REPORT OF: ALTERING CASING [PLUG AND [ABANDONMENT	
12. Check A NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION	dicate N	REMEDIAL WOR COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend	SEQUENT R RK ILLING OPNS. ND M M M M M M M M M M M M M	REPORT OF: ALTERING CASING [PLUG AND [ABANDONMENT	
12. Check NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER:	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION	adicate N	REMEDIAL WOR COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, ar	SEQUENT R RK ILLING OPNS. ND ed Report nd give pertinent of	EPORT OF: ALTERING CASING [PLUG AND [ABANDONMENT	date
12. Check ANOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON TEMPORARILY ABANDON TO THER: 13. Describe proposed or comp	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION	adicate N	REMEDIAL WOR COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, ar	SEQUENT R RK ILLING OPNS. ND ed Report nd give pertinent of	EPORT OF: ALTERING CASING [PLUG AND [ABANDONMENT	date
12. Check A NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON TEMPORARILY ABANDON OTHER: 13. Describe proposed or compostarting any proposed wor recompletion.	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION pleted operations. (Clearly ork). SEE RULE 1103. F	adicate N	REMEDIAL WOR COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, ar le Completions: A	SEQUENT R RK ILLING OPNS. ND ed Report d give pertinent of trach wellbore dia	EPORT OF: ALTERING CASING [PLUG AND ABANDONMENT L Lates, including estimated agram of proposed comple	date
12. Check ANOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Dieted operations. (Clearly ork). SEE RULE 1103. F	adicate N	REMEDIAL WOR COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, and the Completions: A	SEQUENT R RK ILLING OPNS. ND ed Report d give pertinent of trach wellbore dia t @ 12,830'. DV	PLUG AND ABANDONMENT Jates, including estimated agram of proposed comple	date
12. Check ANOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Dieted operations. (Clearly ork). SEE RULE 1103. F	adicate N	COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, ar le Completions: A 0# P-110 casing se and 450 sx PVL tai	SEQUENT R RK	PLUG AND ABANDONMENT lates, including estimated agram of proposed comple Tool Set @ 8,503'. R/U levice and circ.	date
12. Check ANOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Detected operations. (Clearly ork). SEE RULE 1103. F 1 joints 17# HCP-110 w/ 3 stage w/ 500 sx 35/65 PO xx 35/65 POZ/H lead and 2	adicate N	COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, ar le Completions: A 0# P-110 casing se and 450 sx PVL tai adds Plug down @	SEQUENT R RK ILLING OPNS. ND ed Report d give pertinent of ttach wellbore dia t @ 12,830'. DV Drop opening of \$15am. N/D B	PLUG AND ABANDONMENT lates, including estimated agram of proposed comple Tool Set @ 8,503'. R/U levice and circ.	date
12. Check NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON T	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Detected operations. (Clearly ork). SEE RULE 1103. F 1 joints 17# HCP-110 w/ 3 stage w/ 500 sx 35/65 PO xx 35/65 POZ/H lead and 2	adicate N	COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, ar le Completions: A 0# P-110 casing se and 450 sx PVL tai adds Plug down @	SEQUENT R RK ILLING OPNS. ND ed Report d give pertinent of ttach wellbore dia t @ 12,830'. DV Drop opening of \$15am. N/D B	PLUG AND ABANDONMENT lates, including estimated agram of proposed comple Tool Set @ 8,503'. R/U levice and circ.	date
12. Check NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON T	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Detected operations. (Clearly ork). SEE RULE 1103. F 1 joints 17# HCP-110 w/ 3 stage w/ 500 sx 35/65 PO xx 35/65 POZ/H lead and 2	adicate N	COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, ar le Completions: A 0# P-110 casing se and 450 sx PVL tai adds Plug down @	SEQUENT R RK ILLING OPNS. ND ed Report d give pertinent of ttach wellbore dia t @ 12,830'. DV Drop opening of \$15am. N/D B	PLUG AND ABANDONMENT lates, including estimated agram of proposed comple Tool Set @ 8,503'. R/U levice and circ.	date
12. Check NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON T	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Dieted operations. (Clearly ork). SEE RULE 1103. Fill 1 joints 17# HCP-110 w/ 3 stage w/ 500 sx 35/65 PO xx 35/65 POZ/H lead and 2 x,500# high-250# low. Fir	dicate N	SUE REMEDIAL WOR COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, and le Completions: A 0# P-110 casing se and 450 sx PVL tai adds Plug down (a grits. Release Rig	SEQUENT R RK ILLING OPNS. I	EPORT OF: ALTERING CASING [PLUG AND ABANDONMENT Lates, including estimated agram of proposed completed agram of	date etion
12. Check NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON T	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Deted operations. (Clearly ork). SEE RULE 1103. If 1 joints 17# HCP-110 w/ 3 stage w/ 500 sx 35/65 PO xx 35/65 POZ/H lead and 2 x,500# high-250# low. Fir	dicate N	REMEDIAL WORE COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, and le Completions: A 0# P-110 casing see and 450 sx PVL tail adds Plug down (a) g pits. Release Rig	SEQUENT R RK ILLING OPNS. I	EPORT OF: ALTERING CASING [PLUG AND ABANDONMENT Interpretation of proposed completed agram of proposed complete	date etion
12. Check NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON T	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Deted operations. (Clearly ork). SEE RULE 1103. If 1 joints 17# HCP-110 w/ 3 stage w/ 500 sx 35/65 PO xx 35/65 POZ/H lead and 2 x,500# high-250# low. Fir	dicate N	REMEDIAL WORE REMEDIAL WORE COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, and le Completions: A 0# P-110 casing see and 450 sx PVL tail adds Plug down (a) g pits. Release Rig	SEQUENT R RK ILLING OPNS. I	EPORT OF: ALTERING CASING [PLUG AND ABANDONMENT Interpretation of proposed completed agram of proposed complete	date etion
12. Check NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON TO Starting any proposed wor recompletion. 13. Describe proposed or compost starting any proposed wor recompletion. 14.26/05 R/U casing crew. Run 26.5 Schlumberger and circ. Cement 1st 1st 1st 2pt 2pt 2pt 32.5 Schlumberger and circ. Cement 1st 1st 2pt 32.5 Schlumberger and circ. Cement 1st 1st 2pt 32.5 Schlumberger and circ. Cement 2st 2pt 32.5 Schlumberg	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Dieted operations. (Clearly ork). SEE RULE 1103. Fill 1 joints 17# HCP-110 w/ 3 stage w/ 500 sx 35/65 PO x 35/65 POZ/H lead and 2 x,500# high-250# low. Fir above is true and complete closed according to NMOCD	dicate N	REMEDIAL WORD REMEDIAL WORD COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, ar le Completions: A 0# P-110 casing se and 450 sx PVL tai adds Plug down @ g pits. Release Rig est of my knowledged, a general permit E	SEQUENT R ILLING OPNS. ILLING OPNS. IND Med Report Ind give pertinent of trach wellbore dia It @ 12,830°. DV I. Drop opening of the diameter of the dia	ALTERING CASING [PLUG AND [ABANDONMENT lates, including estimated agram of proposed completory of the completory of t	date etion
12. Check NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON T	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Dieted operations. (Clearly ork). SEE RULE 1103. Fill 1 joints 17# HCP-110 w/ 3 stage w/ 500 sx 35/65 PO x 35/65 POZ/H lead and 2 x,500# high-250# low. Fir above is true and complete closed according to NMOCD	dicate N	REMEDIAL WORE REMEDIAL WORE COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, and le Completions: A 0# P-110 casing see and 450 sx PVL tail adds Plug down (a) g pits. Release Rig	SEQUENT R ILLING OPNS. ILLING OPNS. IND Med Report Ind give pertinent of trach wellbore dia It @ 12,830°. DV I. Drop opening of the diameter of the dia	EPORT OF: ALTERING CASING [PLUG AND ABANDONMENT Interpretation of proposed completed agram of proposed complete	date etion
12. Check NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON TO Starting any proposed wor recompletion. 13. Describe proposed or compost starting any proposed wor recompletion. 14/26/05 R/U casing crew. Run 26 Schlumberger and circ. Cement 1st o4/27/05 Cement 2nd stage w/ 325 st L/D BOP and install C-Section @ 2 I hereby certify that the information grade tank has been/will be constructed of SIGNATURE	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Deleted operations. (Clearly ork). SEE RULE 1103. For stage w/ 500 sx 35/65 POx x 35/65 POZ/H lead and 2 y,500# high-250# low. Fir tabove is true and completer closed according to NMOCD	dicate N dicate N state all p state all p for Multip 38 joints 20 Z/H lead a 200 sx H + hish jetting te to the be guidelines f	SUE REMEDIAL WOF COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, at le Completions: A 0# P-110 casing se and 450 sx PVL tai adds Plug down @ prits. Release Rig est of my knowled staff Engineer Staff Engineer	SEQUENT R ILLING OPNS. ILLING OPNS. IND Ed Report Ind give pertinent of trach wellbore dia It @ 12,830'. DV I. Drop opening of the diameter of the diam	PLUG AND ABANDONMENT lates, including estimated agram of proposed completory. Tool Set @ 8,503'. R/U levice and circ. OP, Set slips, cut off casing the certify that any pit or believed the completory. OH 128/05	date etion
12. Check NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON TO Starting any proposed wor recompletion. 13. Describe proposed or compost starting any proposed wor recompletion. 14.26/05 R/U casing crew. Run 26.5 Schlumberger and circ. Cement 1st 1st 1st 2pt 2pt 2pt 32.5 Schlumberger and circ. Cement 1st 1st 2pt 32.5 Schlumberger and circ. Cement 1st 1st 2pt 32.5 Schlumberger and circ. Cement 2st 2pt 32.5 Schlumberg	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Dieted operations. (Clearly ork). SEE RULE 1103. Fill 1 joints 17# HCP-110 w/ 3 stage w/ 500 sx 35/65 PO x 35/65 POZ/H lead and 2 x,500# high-250# low. Fir above is true and complete closed according to NMOCD	dicate N dicate N state all p state all p for Multip 38 joints 20 Z/H lead a 200 sx H + hish jetting te to the be guidelines f	REMEDIAL WORD REMEDIAL WORD COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, ar le Completions: A 0# P-110 casing se and 450 sx PVL tai adds Plug down @ g pits. Release Rig est of my knowledged, a general permit E	SEQUENT R ILLING OPNS. ILLING OPNS. IND Ed Report Ind give pertinent of trach wellbore dia It @ 12,830'. DV I. Drop opening of the diameter of the diam	PLUG AND ABANDONMENT lates, including estimated agram of proposed completory. Tool Set @ 8,503'. R/U levice and circ. OP, Set slips, cut off casing the certify that any pit or believed the completory. OH 128/05	date etion
12. Check NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or compost starting any proposed wor recompletion. 04/26/05 R/U casing crew. Run 26 Schlumberger and circ. Cement 1st 04/27/05 Cement 2nd stage w/ 325 s L/D BOP and install C-Section @ 2 I hereby certify that the information grade tank has been/will be constructed of SIGNATURE Type or print name Josh Fernau	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Deleted operations. (Clearly ork). SEE RULE 1103. For stage w/ 500 sx 35/65 POx x 35/65 POZ/H lead and 2 y,500# high-250# low. Fir tabove is true and completer closed according to NMOCD	dicate N dicate N state all p state all p for Multip 38 joints 20 Z/H lead a 200 sx H + hish jetting te to the be guidelines f	SUE REMEDIAL WOF COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, at le Completions: A 0# P-110 casing se and 450 sx PVL tai adds Plug down @ prits. Release Rig est of my knowled staff Engineer Staff Engineer	SEQUENT R ILLING OPNS. ILLING OPNS. IND Ed Report Ind give pertinent of trach wellbore dia It @ 12,830'. DV I. Drop opening of the diameter of the diam	PLUG AND ABANDONMENT lates, including estimated agram of proposed completory. Tool Set @ 8,503'. R/U levice and circ. OP, Set slips, cut off casing the certify that any pit or believed the completory. OH 128/05	date etion
12. Check NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON TO Starting any proposed wor recompletion. 13. Describe proposed or compost starting any proposed wor recompletion. 14/26/05 R/U casing crew. Run 26 Schlumberger and circ. Cement 1st o4/27/05 Cement 2nd stage w/ 325 st L/D BOP and install C-Section @ 2 I hereby certify that the information grade tank has been/will be constructed of SIGNATURE	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Deleted operations. (Clearly ork). SEE RULE 1103. For stage w/ 500 sx 35/65 POx x 35/65 POZ/H lead and 2 y,500# high-250# low. Fir tabove is true and completer closed according to NMOCD	dicate N dicate N state all p state all p for Multip 38 joints 20 Z/H lead a 200 sx H + hish jetting te to the be guidelines f	SUE REMEDIAL WOF COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, at le Completions: A 0# P-110 casing se and 450 sx PVL tai adds Plug down @ g pits. Release Rig est of my knowled A, a general permit	SEQUENT R ILLING OPNS. ILLING OPNS. IND Ed Report Ind give pertinent of trach wellbore dia It @ 12,830'. DV I. Drop opening of the diameter of the diam	PLUG AND ABANDONMENT lates, including estimated agram of proposed completory. Tool Set @ 8,503'. R/U levice and circ. OP, Set slips, cut off casing the certify that any pit or believed the completory. OH 128/05	date etion
12. Check NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON T	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Deted operations. (Clearly ork). SEE RULE 1103. F 1 joints 17# HCP-110 w/ 3 stage w/ 500 sx 35/65 PO x 35/65 POZ/H lead and 2 ,500# high-250# low. Fir above is true and comple r closed according to NMOCD E-mail add	dicate N	SUE REMEDIAL WOF COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, at le Completions: A 0# P-110 casing se and 450 sx PVL tai adds Plug down @ g pits. Release Rig est of my knowled A, a general permit	SEQUENT R ILLING OPNS. ILLING OPNS. IND Ed Report Ind give pertinent of trach wellbore dia It @ 12,830'. DV I. Drop opening of the diameter of the diam	ALTERING CASING [PLUG AND [PLUG AND ABANDONMENT] Jates, including estimated agram of proposed completed agram of proposed completed agram of proposed completed and circ. OP, Set slips, cut off casing the certify that any pit or believe and circ. OP, Set slips, cut off casing the certify that any pit or believe and circ. O4/28/05	date etion
12. Check NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON T	Appropriate Box to In ITENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Deleted operations. (Clearly ork). SEE RULE 1103. For stage w/ 500 sx 35/65 POx x 35/65 POZ/H lead and 2 y,500# high-250# low. Fir tabove is true and completer closed according to NMOCD	dicate N	SUE REMEDIAL WOF COMMENCE DR CASING TEST A CEMENT JOB OTHER: Amend pertinent details, at le Completions: A 0# P-110 casing se and 450 sx PVL tai adds Plug down @ g pits. Release Rig est of my knowled A, a general permit	SEQUENT R ILLING OPNS. ILLING OPNS. IND Ed Report Ind give pertinent of trach wellbore dia It @ 12,830'. DV I. Drop opening of the diameter of the diam	PLUG AND ABANDONMENT lates, including estimated agram of proposed completory. Tool Set @ 8,503'. R/U levice and circ. OP, Set slips, cut off casing the certify that any pit or believed the completory. OH 128/05	date etion