

Submit 3 Copies To Appropriate District Office
 District I
 1685 N. French Dr., Hobbs, NM 88240
 District II
 1901 W. Grand Ave., Artesia, NM 88210
 District III
 1000 Rio Brazos Rd., El Paso, NM 87449
 District IV
 1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
 Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
 1220 South St. Francis Dr.
 Santa Fe, NM 87505

Form C-103
 Revised June 10, 2003

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM D-10) FOR SUCH PROPOSALS)		WELL API NO. 30-15-06194
1. Type of Well Oil Well ☐ Gas Well ☐ Other ☒ Salt Water Storage		5. Indicate Type of Lease STATE ☒ FEE ☐
2. Name of Operator Loco Hills GSF LTD		6. State Oil & Gas Lease No. BL-635
3. Address of Operator 1231 Old Santa Fe Rd. Santa Fe, NM 87505		7. Lease Name or Unit Agreement Name Loco Hills
4. Well Location Unit Letter L : 19.25 feet from the South line and 560 feet from the East line Section 22 Township 12.5 Range 28 E NMPM Country Other		8. Well Number 3
11. Elevation (Show whether DR, RKE, HF, GR, etc.) GR		9. OGRID Number 3
10. Pool name or Wildcat		10. Pool name or Wildcat

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK ☒ PLUG AND ABANDON ☐ TEMPORARILY ABANDON ☐ CHANGE PLANS ☐ PULL OR ALTER CASING ☒ MULTIPLE COMPLETION ☐ OTHER: ☐		SUBSEQUENT REPORT OF: REMEDIAL WORK ☐ ALTERING CASING ☐ COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐ CASING TEST AND CEMENT JOB ☐ OTHER: ☐	
---	--	---	--

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Run 2 3/4" tubing, cement well. Set 10' in open hole. 10' at bottom of casing shoe. Run MET (300' for 30 min) using calibrated pressure and temperature recorder. Run 2 3/4" J 55 tubing, nipple up + run open hole in casing test (300' for 4 hr) using a calibrated pressure and temperature recorder.

IF MET ON CASING FAILS. Run CBL - set CIBP - spot 5 sacks cement. Run PL 45 10' 4" casing. Circulate cement up backside to surface. Run RKE + MET on new casing. Install 2 3/4" PL 45 tubing nipple up + run open hole in casing test. Will notify OCA before work and before any test is run.

Estimated start date: 12/1/05

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE **John B. Smith**TITLE **Terminal Operator** DATE **12/1/05**Type of print name **John B. Smith**

E-mail address:

Telephone No. **505-122-73**

(This space for State use)

APPROVED BY:

Accepted for record

NMOCD

TITLE

DATE

Conditions of approval, if any:

MAR 07 2006
 MA 006

1" 2.195 Casing

Swelling 5" Casing

Swelling 5" Casing
between 5" and 4" Casing

500

