

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Oil Cons.
N.M. DIV-Dist. 2
1301 W. Grand Avenue
Artesia, NM 88210

FORM APPROVED
Budget Bureau No. 1004-0135

Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

Use "APPLICATION FOR PERMIT-" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

ELK OIL COMPANY

3. Address and Telephone No.

P. O. Box 310
Roswell, New Mexico 88202-0310

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Section 29, Township 13 South, Range 29 East
600' FSL and 1200' FWL

7. If Unit or CA, Agreement Designation

SOUTH LONE WOLF

8. Well Name and No.

SOUTH LONE WOLF UNIT #2

9. API Well No.

30-005-63074

10. Field and Pool, or Exploratory Area

Southwest Lone Wolf Dev.

11. County or Parish, State

Chaves

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log Form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Intend to plug and abandon well as follows:

- (1) Set 30 sxs cement plug at 9500'-9400', tag. *see below*
- (2) Set 20 sxs plug at 8200'-8100'. *see below*
- (3) Cut and pull 5610' 5 1/2" Casing.
- (4) Set 35 sxs stub plug 50 in/50 out at 5660'-5560', tag.
- (5) Set 35 sxs plug at 4150'-4050'. *see below*
- (6) Set 40 sxs plug (8 5/8 shoe plug) at 2243'-2143', tag.
- (7) Set 40 sxs plug at 370'-270'.
- (8) Set 10 sxs surface plug.
Place mud between all plugs.
- (9) Install dry hole marker.
- (10) Cleanup location.

Plug #1 - Set cnt. plug @ 9630' to 9506' + Tag or set CIBP @ 9506' w/35' cement on top.

Plug #2 - Set 150' plug from 8747' to 8597'

Plug #5 - Set this plug across top of Gloria

14. I hereby certify that the foregoing is true and correct

Signed

Title

President

Date

8/13/03

(This space for Federal or State office use)

Approved by

Title

PE

Date

8/22/03

Conditions of approval, if any.

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

* See instruction on Reverse Side

FS160-5.wks

SEE ATTACHED FOR
CONDITIONS OF APPROVAL