

its junsdiction

## **UNITED STATES** DEPARTMENT OF THE INTERIOR **BUREAU OF LAND MANAGEMENT** SUNDRY NOTICES AND REPORTS ON WELLS



## OCD-ARTESIA FORM APROVED OMB NO. 1004-0135 EXPIRES: NOVEMBER 30, 2000

5. Lease Serial No.

Do not use this form for proposals to drill or to re-enter an					NM7713 6. If Indian, Allottee or Tribe Name	
abandoned well. Use Form 3160-3 (APD) for such proposals  SUBMIT IN TRIPLICATE					o. Il Indian, Allottee of	Tibe Name
					7. Unit or CA Agreeme	ent Name and No.
1a. Type of Well 🕡 Oil Well 🔲 Ga	s Well Other		MA APPENDA		8 Well Name and No.	
2. Name of Operator					West Red Lake Unit 69	
DEVON ENERGY PRODUCTION COMPANY, LP					9. API Well No.	
3 Address and Telephone No.					30-015-28933	
20 North Broadway, Ste 1500, Oklahoma City, OK 73102 405-552-4615					10. Field and Pool, or Exploratory	
4 Location of Well (Report location clearly and in accordance with Federal requirements)*  330 FNL 2050 FEL Unit B Sec 8 T18S R27E					Red Lake; Queen Grayburg San Andres  12. County or Parish 13. State	
					Eddy	NM
CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA						
TYPE OS SUBMISSION			TYPE	OF ACTION		
✓ Notice of Intent	Acidize Alter Casing		Deepen Fracture Treat	☐ Productio☐ Reclamat	on (Start/Resume) [	Water Shut-Off Well Integrity
Subsequent Report	Casing Repair		New Construction	Recomple		Other
Final Abandonment Notice	Change Plans		Plug and Abandon Plug Back	Tempora Water Di	rily Abandon	
13 Describe Proposed or Completed Operations (C		s, and give pertine	ent dates, including estimated d	ate of starting ar	ny proposed work and approxim	
deepen directionally or recomplete horizontally, give so the Bond No on file with BLM/BIA Required subsequ						
interval, a Form 3160-4 shall be filed once testing has determined that the site is ready for final inspection)	been completed Final Aband	Ionment Notices s	hall be filed only after all requir	ement, including	reclamation, have been comple	eted, and the operator has
Devon would like to request a TA extension until December 30, 2008, to allow time for partner approval and rig schedule before						
P&A.				<u>`</u>	• •	
Diver 9 Alexander as ant Drace dive						ļ
Plug & Abandonment Procedure:						
1. MIRU. TIH to CIBP @ 1121'. Circulate wellbore w/10 ppg mud.						
2. Spot 30 sx cement in 5-1/2" casing on top of CIBP @ 1121'. WOC & Tag. Calc. PBD @ 825'. (8-5/8" casing shoe @ 1003')						
3. Spot 25 sx cement surface plug @ 247'						
4. Cut wellhead off, set dry hole marker and clean location.						
/ -						
į <b>AC</b>	cer: or lec	ord				
}	NMOCD	ð				
					APPDOM	
,					APPROV	<u> </u>
SEE VITACUED I	-OD			1 1	JUL 27 200	)8
SEE ATTACHED FOR						
CONDITIONS OF APPROVAL  JAMES A. AMOS						$\frac{1}{8}$
				L	SUPERVISOR-EF	PS .
14. I hereby certify that the foregoing is t	ruo and correct					
	and correct	Name	Ronnie Slack			
Signed Kommo Star	R	Title	Engineering Techr		Date	7/18/2008
(This space for Federal or State Office us	se)				<del></del> -	
Approved by		Title			Date	
Conditions of approval, if any		_ ···· <u>~</u>		<u> </u>		