Submit 1 Copy To Appropriate District Office	Energy, Minerals and Natural Resources		Form C-103	
District I			October 13, 2009 WELL API NO.	
1625 N. French Dr., Hobbs, NM 88240 District II	OVE GOVERNMENT DIVIDION		005-63989	
1301 W. Grand Ave., Artesia, NM 88210			5. Indicate Type	
District III 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Francis Dr.		STATE	FEE K
District IV	Santa Fe, NM 87505		6. State Oil & G	as Lease No.
1220 S. St. Francis Dr., Santa Fe, NM				
87505 SUNDRY NOTI	CES AND REPORTS ON WELLS		7. Lease Name of	or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A				
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)			Sam's Ranch	16
1. Type of Well: Oil Well Gas Well X Other Dry Hole			8. Well Number	1
2. Name of Operator			9. OGRID Number	
Primexx Operating Corporation			153888	
3. Address of Operator			10. Pool name or Wildcat	
4849 Greenville Ave., Ste. 1600				
4. Well Location	1000			
Unit Letter 1:	1980 feet from the South	line and		om the <u>East</u> line
Section 16		ange 28E	NMPM Chaves	County
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3567' GR				
<u> </u>			3307 @dax	
12 Charle	Annuantiata Day ta Indiasta N	latura of Notica	Donort or Othor	r Data
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data				
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:				
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON 【 REMEDIAL WORK ☐ ALTERING CASIN				
TEMPORARILY ABANDON				P AND A
PULL OR ALTER CASING				
DOWNHOLE COMMINGLE				
OTHER:	. \square	OTHER:	•	
13. Describe proposed or comp	leted operations. (Clearly state all	pertinent details, ar	nd give pertinent dat	tes, including estimated date
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of				
proposed completion or recompletion.				
1 10001			70	CD 24 h
1. RUPU, opên valve on casing swedge, blow down well.				
2. Remove swedge, screw on wellhead. 3. Install BOP				
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. 1. RUPU, copen valve on casing swedge, blow down well. 2. Remove swedge, screw on wellhead. 3. Install BOP 4. Run tubing to TD, hook up tubing annulus to open top tank w/sugar in bottom				
5. Pump 220 sacks of cement down tubing, pulling the out of well as we go. Circulate wellhore to				
open tank with sugar in bottom.				
6. ND BOP				RECEIVED
7. RDPU				ILCLIAED
8. Cut off casing & weld on cape & 3" X 4' dry hole marker on top of cas			casing cap.	OCT 25 2010
				00. 20.20.0
				NMOCD ARTESIA
Spud Date:	Rig Release Da	ate:		
L				
I hereby certify that the information	above is true and complete to the be	est of my knowled	ge and belief.	
Λ .	4.		v .	
SIGNATURE Malea 1	Nolinan TITLE R	egulatory Analys	st D	ATE 10/10/2010
	And the second of the second o			
Type or print name Andrea Molin	E-mail address	s: anurea.molina	ireprimexx.com Pl	HONE: <u>214-369-5909</u>
For State Use Only	-D .			
APPROVED BY:	TITLE		DA	ATE 10/27/2010
Conditions of Approval (if any):		val Granted providi	ng work	///

Approval Granted providing work is complete by 1/27/20//