

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

CISF
Ep

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION

2040 Pacheco St.
Santa Fe, NM 87505

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO. 30-005-60676
Indicate Type of Lease STATE <input type="checkbox"/> FEE <input type="checkbox"/>
State Oil & Gas Lease No. K4321
Lease Name or Unit Agreement Name Alto State
Well No. 2
Pool name or Wildcat Und. Double L Queen

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

Type of Well:
OIL WELL GAS WELL OTHER

Name of Operator
Saga Petroleum

Address of Operator
415W. Wall Suite 835 Midland Texas 79701

Well Location
Unit Letter J : 1650 Feet From The South Line and 1650 Feet From The East Line
Section 1 Township 15S Range 29E NMPM Chaves County

Elevation (Show whether DF, RKB, RT, GR, etc.)
3865 Gr.

11 Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>
	PLUG AND ABANDON <input checked="" type="checkbox"/>
	PLUG AND ANBANDONMENT <input type="checkbox"/>
	CHANGE PLANS <input type="checkbox"/>

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Notify O.C.D. 24 hrs. before start P.A. operation
2. MIRU rig POH w/ rods & tubing
3. set CIBP @ 1850' w/ 35' cmt. on top
4. RIH circulate well w/ 9.8# mud
5. Spot 100' plug @ 1300' (bottom of salt) **25sx cement Plug 1250' TAG**
6. spot 100' plug @ 415' (8 5/8 set @ 365') woc tag
7. circulate cmt from 30' to surface
8. cut off well head install dry hole marker



* All cement Plugs Min. 25sx
* Notifie N.M.O.C.D. to witness Plugging Operations.
I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Wayne Brooks TITLE agent DATE 04-14-20
TYPE OR PRINT NAME Wayne Brooks TELEPHONE NO 915-5807161

(This space for State Use)
APPROVED BY Mike Sheffield TITLE Field Rep II DATE 4/19/2000
CONDITIONS OF APPROVAL, IF ANY: