

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

C15F  
OP

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

**SUBMIT IN TRIPLICATE**

1. Type of Well <input type="checkbox"/> Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other	5. Lease Designation and Serial No. <u>NMLC045818A</u>
2. Name of Operator <u>Pronghorn Mgt. Corp.</u>	6. If Indian, Allottee or Tribe Name
3. Address and Telephone No. <u>P.O. Box 1772 Hobbs N.M. 88241 505-370-3033</u>	7. If Unit or CA, Agreement Designation
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) <u>SE NW Sec. 18 - T17S - R28E</u>	8. Well Name and No. <u>Hastie # 8</u>
	9. API Well No. <u>30-015-01424</u>
	10. Field and Pool, or Exploratory Area <u>Empire Yates 7 Rivers</u>
	11. County or Parish, State <u>Eddy</u>

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back
	<input type="checkbox"/> Casing Repair
	<input type="checkbox"/> Altering Casing
	<input type="checkbox"/> Other
	<input type="checkbox"/> Change of Plans
	<input type="checkbox"/> New Construction
	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Move in and rig up.
2. Poot with tubing
3. Plug well with ready mix concrete from total depth to surface.
4. Install day hole marker 60' of cement must be placed on back side of 7" psg - 0'-60'
5. Clean location.

If ready mix is used, a minimum of 47 cu ft must be used. Fluid level must be monitored for 30 min. If fluid falls TOC must be obtained and csg. filled. If less is used in csg. information on where the cement is must be provided to OCD for evaluation or the plug drilled out and reset.

14. I hereby certify that the foregoing is true and correct

Signed [Signature]

Title Plantway

Date 03/18/02

(This space for Federal or State office use)

Approved by [Signature]  
Conditions of approval, if any:

Title Field Rep

Date APR 1 2002