

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well <input checked="" type="checkbox"/> Oil Well <input type="checkbox"/> Gas Well <input type="checkbox"/> Other	7. If Unit or CA, Agreement Designation Grayburg Jackson
2. Name of Operator Pendragon Energy Partners, Inc.	8. Well Name and No. 7-5 TR. 7 #5
3. Address and Telephone No. 621 17th St., Ste. 750, Denver, CO 80293 303) 296-9402	9. API Well No. 30-015-04295
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 330' FSL & 1270' FWL Sec. 23 T-17-S R-30-E	10. Field and Pool, or Exploratory Area
	11. County or Parish, State Eddy, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION	
<input type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Other	<input type="checkbox"/> Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*
- 2-23-01 Set CIBP @ 3000', Capped w/ 35' cmt.
 - 2-23-01 Mix mud & Circulate hole.
 - 2-24-01 Cut 7" csg. @ 500'.
 - 2-24-01 Spot 25 sx cmt. @ 1400'.
 - 2-24-01 Spot 50 sx cmt. @ 550'.
 - 2-26-01 Tag plug @ 375'.
 - 2-26-01 Perf 4 holes @ 50'.
 - 2-26-01 Spot 40 sx cmt. to Surface down 8-5/8" csg. & ground. Leave 8-5/8" csg. full of cmt.
 - 2-26-01 Install dry hole marker.

14. I hereby certify that the foregoing is true and correct

Signed <u>[Signature]</u>	Title <u>Agent</u>	Date <u>2-27-01</u>
(This space for Federal or State office use)		
Approved by <u>Record Only</u>	Title <u></u>	Date <u>3/19/01</u>
Conditions of approval, if any:		