Capy to S.7.

NMOCC COPY

SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.) RECELVED ANAME OF OPERATOR P.O. BOX 730 Hobbs, New Mexico 88240 LOCATION OF WELL (Report location clearly and in accordance with any SALESMANDREICA See also space 17 below.) At surface 1980 FSL & 1980 FWL 14. PERMIT NO. 15. ELEVATIONS (Show whether DF, RT, CR, etc.)	6. IF INDIAN, ALLOTTEE OR TRIBE NAME 7. UNIT AGREEMENT NAME Skelly Unit 8. FARM OR LEASE NAME 9. WELL NO. 23 10. FIELD AND FOOL, OR WILDCAT Grayburg Jackson 11. Sec., T., E., M., OR BLX. AND SURVEY OR AREA 14-17-31 12. COUNTY OR PARISH 13. STATE
OIL WE'LL X WELL OTHER 2. NAME OF OPERATOR Getty Oil Company P.O. Box 730 Hobbs, New Mexico 88240 1. Location of Well (Report location clearly and in accordance with any Same also space 17 below.) At surface 1980 F5L \(\frac{\psi}{2}\) 1980 FWL	Skelly Unit 8. FABM OR LEASE NAME 9. WELL NO. 23 10. FIELD AND POOL, OR WILDCAT Grayburg Jackson 11. SEC., T., E., M., OR BLK, AND SURVEY OR AREA 14-17-31
3. ADDRESS OF OPERATOR P.O. Box 730 Hobbs, New Mexico 88240 4. Location of Well (Report location clearly and in accordance with any Serial Deficiency At surface 1980 F5L £ 1980 FWL	23 10. FIELD AND POOL, OR WILDCAT Grayburg Jackson 11. SEC., T., E., M., OR BLK. AND SURVEY OR AREA 14-17-31
See also space 17 below.) At surface 1980 F5L & 1980 FWL	Grayburg Jackson 11. SEC., T., E., M., OR BLK. AND SURVEY OR AREA 14-17-31
14 PROMIT NO. 1.15 PIGNATIONS (Chart whather on the Co. o.)	12 COUNTY OF PURISH 13 STATE
15. ELEVATIONS (Show whether Dr. RT, CR. etc.) 3 90 9 D.F.	Eddy N.M.
16. Check Appropriate Box To Indicate Nature of Notice, Report, or	Other Data
PULL OR ALTER CASING PRACTURE TREAT SHOOT OR ACIDIZE BEPAIR WELL (Other) Bring cement above 7-Rivers T. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent date proposed work. If well is directionally drilled, give subsurface locations and measured and true vertinent to this work.)* (1) Pull rods and tubing. (2) Run Cement Bond Log. (3) Perforate and bring cement above top of 7-Rivers. (4) Run Temperature Survey. (5) Drill out cement. (6) Rerun tubing and rods. (7) Place well on production.	REPAIRING WELL ALTERING CASING ABANDONMENT* Is of multiple completion on Well pletion Report and Log form.) s, including estimated date of starting any cal depths for all markers and zones perti-
RECE	B 16 1978 BENLUNIAN MEN MENICO MENAN MEN MENICO

(This space for Federal or Start office use)