

Skelly Unit #1  
Eddy County, New Mexico  
Page 2

- 9) Open sliding sleeve and swab fluid out of hole.
- 10) Run tubing with bull plugged mud anchor and seating nipple set at approximately 12,050'. Swab fluid, if any, out of well.
- 11) Hook up to flow gas through the annulus and provide gas to Skelly Unit Plant No. 1.
- 12) Inject water in Well No. 30 for 10 days and run injection profiles.

RECEIVED

001 2 - 1972

O. C. C.  
OFFICE OF THE COMMISSIONER

RECEIVED  
001 2 - 1972  
O. C. C.  
OFFICE OF THE COMMISSIONER

Page 10

The following information was obtained from the records of the  
Department of the Interior, Bureau of Land Management, for the  
year ending December 31, 1964:

RECEIVED

1965

1964