

Form 9-331
(May 1963)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-029420(A)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

Skelly Unit

8. FARM OR LEASE NAME

Skelly Unit

9. WELL NO.

32

10. FIELD AND POOL, OR WILDCAT

Grayburg-Jackson11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA**Sec. 15-178-31E**

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico**SUNDRY NOTICES AND REPORTS ON WELLS**
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ **Water Injection**

2. NAME OF OPERATOR

Skelly Oil Company

3. ADDRESS OF OPERATOR

P. O. Box 1351, Midland, Texas 797014. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface**660' FSL and 660' FEL, Sec. 15-178-31E**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3882' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐

(Other)

PULL OR ALTER CASING ☐MULTIPLE COMPLETION ☐ABANDON* ☐CHANGE PLANS ☐**Squeeze perforations****X**

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)***To attain more efficient vertical distribution of injected water, we propose the following work:**

- 1) Rig up workover rig. Pull tubing and packer.
- 2) Spot 20-40 sand from bottom back to 3260'.
- 3) Run tubing and set packer at approximately 3150'.
- 4) Break down and cement perforations 3231', 3241', and 3251', with 100 sacks expanding-type cement. Overflush with 2 bbls. water. WOC 4 hours and recement with 40 sacks expanding-type cement. If squeeze pressure is obtained, reverse out excess cement; if not, repeat.
- 5) Clean out to 3803'
- 6) Return well to injection status.

RECEIVED
DEC 1 1971
U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct.

SIGNED

D. R. DOW

TITLE

Lead Clerk

DATE

Nov. 30, 1971

(This space for Federal or State office use)

APPROVED BY

CONDITION OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED
DEC - 1 1971
H. L. BECKMAN
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local, Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones or other zones with present significant fluid contents not sealed off by cement or otherwise; depth (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled; and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looks to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1963 O-685229

847-485