

- 1 If $2\frac{7}{8}$ is cut + pulled up will need a stub plug 50' in + out of slab + tag.
- 2 Place a 100' plug across 7" csq shoe + 110' + tag or bring the cement on to surface from 50' below shoe.
- 3 If $2\frac{7}{8}$ is not cut + pulled perforate above free-point + squeeze 25 sh leaving 100' plug in side of $2\frac{7}{8}$
- 4 Perforate $2\frac{7}{8}$ @ 140' + bring cement to surface leaving $2\frac{7}{8}$ full also.