

N. M. O. & G. COPY
UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN THE (CATE)
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.
V.L.Foster 049998 (a)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR
WEIER DRILLING COMPANY

3. ADDRESS OF OPERATOR
P.O. BOX 1266, MONAHANS, TEXAS 79756

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface Located 2310' from North line and 1650'
from East line of Section 17, Twp. 17S, Range 31 E.
N.M.P.M. SW/4 of NE/4.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
V.L.Foster

9. WELL NO.

6

10. FIELD AND POOL, OR WILDCAT

Grayburg-Jackson

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

17-17S-31E N.M.P.M.

12. COUNTY OR PARISH
Eddy

13. STATE
New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) Convert to Water Inj. Well X

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

We request permission to convert V.L.Foster Well #6 to water injection well to conform with the Sinclair Keel West Waterflood project. Our planned operational procedure is stated below. This work will commence as soon as possible after approval of both U.S.G.S. and the New Mexico Oil Conservation Commission.

Operational Procedure Plans:

1. Move in and rig up pulling unit.
2. Pull Rods and Tubing.
3. Rerun Tubing with packer.
4. Set packer @ approximately 2850', inside 4½" Casing.
5. Install Injection Head.
6. Start water into well.

RECEIVED

1968

RECEIVED
FEB 6 1968
U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Partner

DATE February 6, 1968

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED
FEB - 5 1968

R. L. BLUMMAN
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side