SHOOT OR ACIDIZE ABANDON\* SECOTING OR ACIDIZING ABANDONMENT\* REPAIR WELL CHANGE PLANS (Other) Temporarily Abandon (Other) (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

WATER SHUT-OFF

FRACTURE TREATMENT

PULL OR ALTER CASING

MULTIPLE COMPLETE

TEST WATER SHUT-OFF

PRACTURE TREAT

N.M.

REPAIRING WELL

ALTERING CASING

This well has been temporarily abandoned in the following manner: Pulled tubing and capped well w/2000# WOG valve. 3/2/73. Well will be held for waterflood study.

RECTIVED

APP 1 1973

11, 9, 9, ARTEDIA. OFFICE

18. I hereby certify that the foregoing is true and correct			
SIGNED C.L. Antoken	TITLE Dist. Drlg.	Supervisor	DATE 4/4/73
APPROVED BY CONDITIONS OF APPROVAL, IF ANY:	TITLE		DATE

\*See Instructions on Reverse Side