

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRI-STATE\*  
(Other instructions on reverse side)

Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE IDENTIFICATION AND SERIAL NO.

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR RANCH NAME

9. WELL NO.

10. FIELD AND POOL, OR WILDCAT

11. SEC., T., R., NE, OR SE, AND SURVEY OF AREA

12. COUNTY OR PARISH

13. STATE

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Skelly Oil Company

3. ADDRESS OF OPERATOR

P. O. Box 1351, Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\* See also space 17 below.)

At surface

660' FSL and 1980' FWL of Sec. 23-178-31E

14. PERMIT NO.

Order No. WFX-327

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3862' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) Convert to water injection

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

SUBSEQUENT REPORT

REPAIRING WELL

REPAIRING CASING

ABANDONMENT\*

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

This well has been producing from perforations 3281-3610' and from open-hole sections 3634-3894'. We propose the following work which has been approved under Administrative Order No. WFX-327.

- 1) Move in and rig up workover rig.
- 2) Pull rods
- 3) Spot 500 gals. 15% acid down tubing.
- 4) Pull tubing
- 5) Run coated injection tubing and injection packer. Set packer at approximately 3231'.
- 6) Load casing annulus with inhibited fluid.
- 7) Hook to injection system and start injecting.

This will be a water injection well for the Skelly Unit, operated by Skelly Oil Company.

RECEIVED

JUN 8 1970

R. L. BEEKMA

ARTESIA, NEW MEXICO

RECEIVED

JUN - 5 1970

U. S. GEOLOGICAL SURVEY  
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED (Signed) J. R. Avent

TITLE Dist. Adm. Coordinator

DATE June 2, 1970

(This space for Federal or State office use)

APPROVED BY  
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED

JUN - 5 1970

R. L. BEEKMA

ACTING DISTRICT SUPERVISOR

\*See Instructions on Reverse Side

# Instructions

**General:** This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

**Item 4:** If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

**Item 17:** Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data, readily obtainable for present productive zones or other zones with present significant fluid contents, not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; and of either material placed below, between and above plugs; amount, size, method of setting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1965 O-685229

RECEIVED

RECEIVED

APPROVED

H. L. BECKMAN

\*See instructions on Reverse Side

## SUNDRY NOTICES AND REPORTS ON WELLS

DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY  
UNITED STATES

(The user of this form is requested to fill in the spaces or check back to a different page as indicated for each purpose.)

NAME OF OPERATOR

ADDRESS OF OPERATOR

CITY AND STATE

CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE REPORT OR OTHER ACTION

ABANDONMENT OF WELL  
REPAIR OF WELL  
OTHER

REASON FOR ABANDONMENT

DATE OF ABANDONMENT

DATE OF REPORT

DATE OF INSPECTION

DATE OF CLOSURE

DATE OF RE-ENTRY