

Proposed Program (cont.)

8. of 4½" casing stub. [TAG PLUG] SJS
9. Pump Plug #3 (35sx)-(5482'-5382'). Plug #3 covers top of Abo formation.
10. Pump Plug #4 (35sx)-(3552'-3453'). Plug #4 extends 50' in & out of 9-5/8" casing shoe. [TAG PLUG] SJS
11. Perforate Seven Rivers and/or Queen zones around 2200' inside 9-5/8" casing.
12. Acidize and/or frac.
13. Run tbg and rods; set pumping unit & heater treater.
14. Put well on pump.