

Operator

Ready Oil & Gas Mgmt.

Well

Turner Federal #14

Unit

15

Section

13

Township

20

Range

28

API #

30-015-02385

TOPS

Salada 455'

B Salt 620'

Lyons ~ 750'

← Surface Plug

No Cement

8 5/8" @ 363'
Mud

← Shoe Plug 413' Tag

383' - 1st TOC

7" @ 1712'
75 SXS.

← 712' Tag

04 835'

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

10.