

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED

Budget Bureau No. 1004-0135

Expires November 30 2000

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

5. Lease Serial No.

NM 04827-B

6. Indian, Allottee or Tribe Name

7. If Unit or CA/Agreement, Name and/or No.

8. Well Name and No.

MOC FEDERAL #3

9. API Well No.

30-015-28045

10. Field and Pool, or Exploratory Area

SOUTH DAGGER DRAW UPPER PENN  
ASSOCIATED POOL

11. County or Parish, State

EDDY

NM

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent  
☒ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Acidize ☐ Deepen ☐ Production (Start/Resume) ☐ Water Shut-Off  
☐ Alter Casing ☐ Fracture Treat ☐ Reclamation ☐ Well Integrity  
☐ Casing Repair ☐ New Construction ☐ Recomplete ☒ Other ADD PERFS  
☐ Change Plans ☐ Plug and Abandon ☐ Temporarily Abandon AND STIMULATE  
☐ Convert to Injection ☐ Plug Back ☐ Water Disposal

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the final site is ready for final inspection.)

Work commenced 3/7/99. MIRU PU. Kill Well. ND wellhead & NU BOPs. POOH w/sub pump. Set RBP @ 2106'. RIH w/overshot to RBP. Release RBP & POOH. Perforate 7" casing w/4 JSPF, 120 degree phasing @ 7448'-7476' and 7482'-7514' (60' of pay, 240 holes). RIH w/PPI tool. Acidize old perfs. (7620'-7610' & 7580'-7556') w/50 gpf of 15% HCl acid for a total of 1700 gals. PUH to new perfs and acidized 7514'-7512' w/100 gpf, 7512'-7482' & 7476'-7470' w/75 gpf & 7470'-7448' w/85 gpf for a total of 8000 gals. of 15% NEFE acid. RIH w/sub pump on 2-7/8" tubing. Latched on RBP, released it and ran on in the hole to previous pump setting depth. ND BOPs & NU wellhead. Made final splice and RD PU on 3/10/99.

14. I hereby certify that the foregoing is true and correct  
Name (Printed/Typed)

Ginny Larke

Title

Engineer Technician

Date 3/18/99

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

Title

Date

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on reverse)