

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. V-3587	

SUNDRY NOTICES AND REPORTS ON WELLS
DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT - II" (FORM C-101) FOR SUCH PROPOSALS.

1. OIL <input type="checkbox"/> GAS <input type="checkbox"/> OTHER- DRY AND ABANDONED		7. Unit Agreement Name NONE
2. Name of Operator BASIN OPERATING COMPANY		8. Farm or Lease Name RUBY STATE
3. Address of Operator SUITE 648 PETROLEUM BUILDING, ROSWELL NM 88201		9. Well No. #1
4. Location of Well UNIT LETTER <u>J</u> <u>2200</u> FEET FROM THE <u>SOUTH</u> LINE AND <u>2200</u> FEET FROM THE <u>EAST</u> LINE, SECTION <u>30</u> TOWNSHIP <u>20S</u> RANGE <u>27E</u> NMPM.		10. Field and Pos., or Wildcat WILDCAT
11. Elevation (Show whether DF, RT, GR, etc.) GL = 3234 KB = 3244		12. County EDDY

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP at 2296' and dumped 5 sx Class C cement on top (2296'-2246')
2. Set 10 sx Class C cement + 3% CaCl₂ at 1672' to 1572'. Tag plug at 1656'. Set 10 sx Class C 1656' to 1566'.
3. Set 10 sx Class C Cement 508' to 408'. Tag plug at 412'.
4. Set 5 sx Class C Cement 50' to Surface.
5. Installed Dry Hole Marker.

Tagging of plugs witnessed by Gary Williams of the OCD. Did not pull any casing.

RECEIVED

MAY - 2 1996

OIL CON. DIV.
DIST. 2

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE President DATE 4/24/96

APPROVED BY Michael C. Stillfield TITLE Field Rep II DATE 6-27-97

CONDITIONS OF APPROVAL, IF ANY: