

12,100-13,200':

Drill Morrow section on air/mist carefully monitoring hole conditions while drilling. Log before loading hole with fluid. Load hole with low fluid loss (3 cc) brine gel/KCL polymer mud prior to running 4-1/2" liner.