

PU and reverse hole clean. POH WOC.

6/13/81 Waiting on cement 24 hours. TIH w/ 3 7/8" bit, DC's and tubing. Circ out green cmt
PU to 9100#. WOC.

6/14/81 TIH with 2 3/8" tubing. Drilled EZSV tat 12540'. Drilled 40' cmt to 12585'.
PU to 9100. Press to 1000#.

6/15/81 SD for Sunday.