

TX 350

13 3/8 400' circ.

(TAG)

305x @ 450' (13 1/2 TX)

25 x @ 1645' (Bx)

Bx 1645

255x @ 2125' (OCCUPANCY)

DELAWARE 2075

255x @ 3700' (<2000' REQ.)

9 5/8 5462' circ

Plug 5350

BOMB Spring 5477

~~5650~~
5650

(TAG)

255x @ 7050' (2000' BS)

— Plug 8768 - 8868

Wolfcamp 8818

DV Tool 9655

— Plug 9605 - 9705

PENN 10,023

STRAWN 10,280

ATOKIN 10660

MORROW LS 11,182
MORROW CHS 11,433

255x @ 9973' (H-4)

255x @ 10330' (SEB-4)

CIBP @ 10450' 37' ANT

Perfs 10,514 - 10590

255x @ 10710' (ATOKIN)

CIBP 11,500 25x cement

Perfs 11,664 - 11,680

Perfs 11,761 - 11,766

Perfs 11,934 - 11,951

5 1/2 12052' 1st Stage Circ

Already
their