

Operator BASS Ent Prod Co  
 Well Poker Lake 42  
 Unit G Section 10 Township 25 Range 30  
 API # 30-015-21095

TOPS

Dates \_\_\_\_\_  
 T. Salt ?  
 B. Salt 3730  
 Glorieta \_\_\_\_\_  
 Bone Sp. 7739  
 Abo \_\_\_\_\_  
 Wolfcamp 11055  
 Morrow 14387  
 Devonian \_\_\_\_\_  
 Fusselman \_\_\_\_\_  
 Other Delaware 3990

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

