UNITED STATES

FORM APPROVED Budget Bureau No. 1004-0135 Expires: March 31, 1993

✓ DEPARTMENT OF T	HE INTERIOR ZWY MAY 12 AM	8: 50
d BUREAU OF LAND N	IANAGEMENT	5. Lease Designation and Serial No. NMNM 020496
SUNDRY NOTICES AND REPORTS ON WELLS		6. If Indian, Allottee or Tribe Name
Do not use this form for proposals to drill or to deepen or reentry to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals		N/A
		7. If Unit or CA, Agreement Designation
SUBMIT IN TRIPLICATE		
1. Type of Well		
\square Oil X Gas \square Other		8. Well Name and No.
2. Name of Operator	2000	Yockey 3 9. API Well No.
Roddy Production Company, Inc. 3. Address and Telephone No.	- W. W	9. AP1 well No. 30-045-06392
- I - I - I - I - I - I - I - I - I - I		10. Field and Pool, or Exploratory Area
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)		West Kutz Pictured Cliffs
		11. County or Parish, State
Surface location; 1850' FNL x 1850' FEL, Section 20, T27N, R11W		San Juan County, New Mexico
12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA		
TYPE OF SUBMISSION TYPE OF ACTION		
	Abandonment	☐ Change of Plans
X Notice of Intent		
TT TOUGHT OF THEORY	☐ Recompletion	New Construction
	Plugging Back	Non-Routine Fracturing
☐ Subsequent Report	Casing Repair	☐ Water Shut-Off
	Altering Casing	Conversion to Injection
☐ Final Abandonment Notice	X Other attempt to produce	Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)
13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depth for all markers and zones pertinent to this work.)* Roddy Production intends to use a pulling unit to test the casing integrity of the above well and determine if the well can be returned to production or if it should be P&A'd. Operations are planned to start by June 1, 2004. A workover procedure and well bore diagram are attached. 14. I hereby certify that the foregoing is true and correct		
Signed Robert R. Griffee	Title Operations Manager	Date: 5/11/04
(This space for Federal or State office use)		
Approved by Original Signed: Stephen Mason	Title	Date MAY 1 9 2004
Conditions of approval, if any:		

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.



DI SIMMONS, INC.

1009 Ridgeway Place Suite 200 Farmington, New Mexico 87401

505-326-3753 505-327-4659 FAX info@djsimmonsinc.com www.djsimmonsinc.com Date: 5/11/2004

Yockey Federal #3 Workover Procedure

- 1. Dig blow pit, check rig anchors.
- 2. MIRU pulling unit and air package.
- 3. Blow down well, ND well head, NU BOPE.
- 4. Attempt to unset packer and POOH with 2 7/8" (probably IJ) tubing and packer. If packer will not unset, jet cut tubing off above packer and TOH.
- 5. PU bit and 2 3/8" tubing. TIH. TIH to PBTD or packer depth.
- 6. TOH.
- 7. PU casing scraper and round trip to PBTD or packer depth.
- 8. TIH with packer. Set packer at 1800'.
- 9. Attempt to pressure test casing to 500 psi.
- 10. Develop plans to return well to production or P&A based on pressure test.

