Form 3160-5 (April 2004)

Subsequent Report

Final Abandonment Notice

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160 - 3 (APD) for such proposals.

Change Plans

Convert to Injection

States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

FORM APPROVED
OM B-No. 1004-0137
Expires: March 31, 200

5.	Lease Sepial No.
	SF-878505

If Indian, Allottee or Tribe Name

				NA.			
SUBMIT IN TRIPLICATE- Other instructions on reverse side.			7. If Unit or CA/Agreement, Name and/or No. NA 8. Well Name and No.				
1. Type of Well Gas Well Other							
2. Name of Operator Koch Exploration Company, LLC			Seymour 722S 9 API Well No.				
3a Address PO Box 489, Aztec, NM 87410		3b. Phone No. (include area code) 505-334-9111		30-045-32608			
				10. Field and Pool, or Exploratory Area			
4. Location of Well (Footage, Sec.,	T., R., M., or Survey Description)	1		Basin F	ruitland Coal		
880' FNL & 1035' FWL, S24, T31N, R9W "D" Lat 36.53.177, Long 107.44.145			11. County or Parish, State San Juan, New Mexico				
						12. CHECK A	PPROPRIATE BOX(ES) TO
TYPE OF SUBMISSION	TYPE OF ACTION						
	Acidize	Deepen	Production (St	art/Resume)	Water Shut-Off		
Notice of Intent	Alter Casing	Fracture Treat	Reclamation	,	Well Integrity		
Subsequent Report	Casing Repair	New Construction	Recomplete		Other Pressure Test		

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

Plug and Abandon

Plug Back

Temporarily Abandon

Water Disposal

• 11/08/05 Rig up and test 7" casing pressured up to 1500# for 30 mintes, held O.K. Tested BOPs 250# low and 200# high for 10 minutes each. Tag cement @2868'. 11/09/05 Rig up mud loggers and drill with 6 1/4" bit, open hole to 3390'. 11/10/05 Ran 5 1/2", 15.50#, J-55 LT&C liner, top @ 2864', bottom @ 3385'. No cement or pressure testing required on 5 1/2" liner.



Intermediate Casing

and Run Liner