

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

Use "APPLICATION FOR PERMIT-" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well <input type="checkbox"/> Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other	5. Lease Designation and Serial No. SF078243
2. Name of Operator Roddy Production Company, Inc.	6. If Indian, Allottee or Tribe Name
3. Address and Telephone No. P.O.Box 2221, Farmington, NM 87499 (505) 325-5750	7. If Unit or CA, Agreement Designation
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 1000' FNL-1800' FWL, Section 19, T31N, R12W, NMPM	8. Well Name and No. Southern Union No. 2E
	9. API Well No. 30 - 045 - 24387
	10. Field and Pool, or Exploratory Area Basin Dakota
	11. County or Parish, State San Juan, NM

12. **CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA**

TYPE OF SUBMISSION	TYPE OF ACTION
<input type="checkbox"/> Notice of Intent	<input type="checkbox"/> Abandonment
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion
<input checked="" type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back
	<input type="checkbox"/> Casing Repair
	<input type="checkbox"/> Altering Casing
	<input checked="" type="checkbox"/> Other <u>install dry hole marker</u>
	<input type="checkbox"/> Change of Plans
	<input type="checkbox"/> New Construction
	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Dispose Water

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

July 29, 2003: Dug out old wellhead. Remove temporary cap. Fill 4 1/2" casing with 11 sacks (5.5 cf) of Quikcrete. Weld dry hole marker on 4 1/2" casing stub. Fill bell hole and level area around dry hole marker. This completes rehab requirements for this wellbore. Location will be rehabed when Owen 2R is plugged and abandoned.

14. I hereby certify the foregoing is true and correct

Signed

Kenneth E. Roddy
KENNETH E. RODDY

Title

President
PRESIDENT

Date August 14, 2003

Approved by

Title

Conditions of approval, if any:

NOTED FOR RECORD
Date

NMOCD

AUG 20 2003

FARMINGTON FIELD OFFICE