

TENTATIVE CEMENTING PROGRAMS

Kane Bros.
Finch #1
0-15-29N-11W

Division-approved Plugging Program

Clean out hole to approx. 960'

Set a cement plug 960'-860' with neat cement

If hole is cased cut & pull casing

Below 750' or perforate at 750' & set a cement plug 750'-600' with neat cement

Set a cement plug 150'-50' with neat cement. If casing is not pulled, perforate at 150'.

Fill pits, clean & level location

A dry hole marker will not be required.

Casing and/or hole sizes are unknown

Should take 80-90 sacks to plug it

All plugs will be a Class A,B or C cement with or without CaCl₂