
submitted in lieu of Form 3160-5

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT



FEB 14 2011

	Sundry Notices and Reports on Wells Bures		mingron Fiero Offic. u of Land Managemen		
1.	Type of Well GAS	5. 6.	Lease Number SF-078020 If Indian, All. or Tribe Name		
2.	Name of Operator	7.	Unit Agreement Nam Huerfano Unit		
	BURLINGTON RESCURCES OIL & GAS COMPANY LP	a	***************************************		
3.	Address & Phone No. of Operator	8.	Well Name & Numbe Huerfano Unit 190		
	PO Box 4289, Farmington, NM 87499 (505) 326-9700	9.	API Well No.		
- 4.	Location of Well, Footage, Sec., T, R, M		30-045-20419		
••	Unit B (NWNE), 1025' FNL & 1840' FEL, Section 1, T25N, R10W, NMPM	10.	Field and Pool Basin Dakota		
		11.	County and State San Juan, NM		
, -	CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, Control of Submission X Notice of Intent Subsequent Report Final Abandonment Final Abandonment Abandonment Abandonment Recompletion Plugging Casing Repair Casing Repair Altering Casing Conversion to Injection		Other – MIT & set packer		
13. Describe Proposed or Completed Operations		RCVD FEB 17'11			
This NOI is to replace the NOI filed 8/24/10 to conduct MIT.			OIL CONS. DIV.		
Pei	r attached procedures and wellbore schematic.		DIST. 3		
14.	MEND REPORT TO INCUDE FAILURE CONTINGENCY AS DISCUSSED 2-17-11 BY CHARLIE PERRIN AND KELLY ROBERTS. I hereby certify that the foregoing is true and correct. Rhonda Rogers Title: Staff Regulation				
	nis space for Federal or State Office use) PROVED BY Original Signed: Stephen Mason Title ONDITION OF APPROVAL, if any:		DateFEB 1 & 201		

NMOCD

An

ConocoPhillips HUERFANO UNIT 190 (DK)

Expense - MIT

Lat 36° 26' 4.56" N

Long 107° 50' 39.588" W

Prepared by:

Tatyana Carr

Date: February 14, 2011

Scope of Work:

to perform a MIT and install a packer at 4200' to enable future rigless MIT's.

Est. Rig Days:

4

Area:

21 DK

Route: 152

Est. Uplift:

36 MCFD

Formation:

Route: 15

WELL DATA

Spud Date: 3/2

LOCATION:

API:

3004520419

S

3/22/1969

LOCATION

Total Depth:

6840'

TBG Depth: 6713' KB:

PBTD: BTM Perf: 6831' 6731'

EOT to PBTD:

118'

1025' FNL & 1840' FEL, Spot B, Section 01 -T 025N - R 010W

BTM Perf to PBTD:

10' 100'

Perforations:

DK: 6642' - 6731'

Tubular	DO	Weight (lbs)	Grade	Connection	۵l	Drift ID	Depth
Casing	8 5/8"	24	J-55	STC	8.097"	7.972"	232'
Casing	4 1/2"	10.5	J-55	LTC	4.052"	3.927"	6837'
SN	2 3/8"		İ			1.780"	6711'
Tubing	2 3/8"	4.7	J-55	EUE	1.995"	1.901"	6713'
Mule_Shoe	2 3/8"			j		1	6712'
	1					[
							•
	1		Ì			1	
	[-	[l l	

Well History/Justification

The Huerfano Unit #190 was drilled in 1969 as a stand alone Dakota producer. Production from the Huerfano Unit #190 fell off and began requiring periodic swabbing due to water loading. MIT was performed and determined the well to have a casing leak. A cement squeeze was performed on 3/31/2009 and failed following pressure test. Permission was obtained from NMOCD and a 300 PSI Seal maker squeeze was performed on 4/4/2009 and passed 500 psi pressure test recorded on chart. As a result of the use of the 300 PSI chemical squeeze, we are obligated to perform an annual MIT to ensure the integrity of the seal and the casing. However, production from the well is not enough to economically support the yearly expense of rig cost to pull tubing and perform MIT.

We propose performing a standard MIT from 6600' to surface by pulling tubing and setting packer 50' above top perforation. If the MIT fails, depending on results, it will be decided to repair the well or to begin abandonment procedure. If the MIT passes, we propose setting a packer at 4200' (139' below cement top 4061' - 4965') which is below previous 300 PSI casing repair in order to enable annual surface MIT testing (without need for expensive rig). A depth of 4200' was selected as it is critical that the packer placement be high enough in the wellbore to supply enough annular compressible volume required to propel a plunger with liquid to the surface. Setting a packer lower would only result in inability to operate a plunger and produce the well.

ConocoPhillips HUERFANO UNIT 190 Expense - MIT

Lat 36° 26' 4.56" N

Long 107° 50' 39.588" W

PROCEDURE

Notify OCD 24 hours ahead to witness MIT testing, call @ 334-6178 ext.# 116

- 1. Hold pre-job safety meeting. Comply with all NMOCD, BLM, and COPC safety and environmental regulations. Test rig anchors prior to moving in rig.
- 2. MIRU work over rig. Check casing, tubing, and bradenhead pressures and record them in Wellview.
- 3. RU blow lines from casing valves and begin blowing down casing pressure. Kill well with 2% KCl, if necessary.
- 4. ND wellhead and NU BOPE. PU and remove tubing hanger and tag for fill, adding additional joints as needed (tubing currently landed @ 6713', PBTD @ 6831') . Record fill depth in Wellview.
- 5. TOOH with tubing (details below).

Number	Description
211	2-3/8" Tubing joint
1	2-3/8" pup joint (2.1')
1	2-3/8" tubing joint
1	2-3/8" F nipple (ID 1.78")
1	2 -3/8 Mule Shoes
1 1 1	2-3/8" F nipple (ID 1.78"

Use Tuboscope Unit to inspect tubing and record findings in Wellview. Make note of corrosion, scale, or paraffin

- 6. Round trip w/ watermelon mill, clean to PBTD @ 6831'.
- 7. RIH with RBP and packer. Set RBP 50' above perfs @ 6592', then set packer @6582' and pressure test the RBP @560 psi. If RBP tests release packer and test casing @560. Record on chart.
- 8. If pressure test fails, release packer and isolate the casing leak. Contact engineer to get further instructions.
- 9. If casing test is successful, retrieve the RBP and TOOH with RBP and packer.
- 10. TIH with the following configuration: NOTE install packer at 4200'

Recommended Tubing Drift ID:

Land Tubing At: 6713'
Land F-Nipple At: 6711'

Number	Description
1	Expandable Check
1	2-3/8" F-nipple
1	2-3/8" full tubing joint
1	2-3/8" pup joint (4.1')
80	2-3/8" tubing joints
~x	2-3/8" Tubing pup joints (as necessary to achieve desired depth of 4200')
1	Lockset Type Packer @ 4200'
140	2-3/8" tubing joints

- 11. Call Nalco and fill the backside with packer fluid.
- 12. ND BOPE, NU Wellhead. Pressure test tubing slowly with an air package as follows: pump 3 bbls pad, drop steel ball, pressure tubing up to 500 psi, and bypass air. Monitor pressure for 15 mins., then complete the operation by pumping off the expendable check. Note in Wellview the pressure in which the check pumped off. Notify the MSO that the well is ready to be turned over to Production Operations. Make swab run to kick-off the well, if necessary, then RDMO.

Tubing Drift Check

- 1. Set flow control in tubing. With air, on location, use expendable check. With no air on location, use wire line plug.
- 2. RU drift tool to a minimum 70' line. Drift tool will have an OD of at least the API drift specification of 1.901" for the 2 3/8",4.7# tubing, and will be at least 15" long. The tool will not weigh more than 10# and will have an ID bore the length of the tool, so fluids may be pumped through the tool if it becomes stuck.
- 3. Drop the tool into the tubing string and retrieve it after every 2 joints of tubing ran in hole. If any resistance to the tool movement is noticed, going in or out, that joint will be replaced.
- 4. In order to stimulate the plunger lift operation, all equipment must be kept clean and free of debris.

The drift tool should be measured with calipers before each job, to ensure the OD is the correct size for the tubing being checked. The maximum allowable wear of the tool is .003".

Current Schematic ConocoPhillips Well Name: HUERFANO UNIT #190 Sentace Legal Location Edit 3004520419 NMPM,001-025N-010VV NEW MEXICO KB-G round Distance righal KB/RT Elevation (f Ground Eleuation (11) KB-Casing Flange Distance (1) KB-Tiblig Hanger Distance (1) 6,798.00 6,808.00 10.00 Well Config: - Original Hole, 8/17/2010 3:28:43 PM ftKB (MD) Schematic - Actual Frm Final Surface Casing Cement, 10-232, 3/22/1969, 10 Cemented with 160 sxs Class A. Circulated 231 to surface. Surface, 8 5/8in, 8.097in, 10 ftKB, Set depth 232 adjusted from 12' KB to production KB of 10'., 232 ftKB 236 1,213 OJO ALAMO, 1,213 1,420 KIRTLAND, 1,420 -1,817 FRUITLAND, 1,817 Production Casing Cement, 1,655-2,328, 2,160 PICTURED CLIFFS, 2,160 4/2/1969, 3rd Stage: Lead with 115 sxs Class C and tailed with 50 sxs Class C neat. 2,326 Top of cement @ 1655' per cement top calc. Cement Squeeze, 3,810-3,870, 3/31/2009, 2,328 Tubing, 2 3/8in, 4.70lbs/ft, J-55, No pressure test. 300 psi squeeze, 3.810-3.870, 4/4/2009, 3,730 10 ftKB, 6,678 ftKB MESAVERDE, 3,730 Pressure test to 500#. Record on chart. 4,653 POINT LOOKOUT, 4,653 Production Casing Cement, 4,061-4,925, 4,924 4/2/1969, 2nd Stage: Lead with 165 sxs 4,925 Class C and tailed with 50 sxs Class C neat. Top of cement @ 4061' per cement top 5,715 GALLUP, 5,715 calculation. 6,540 GREENHORN, 6,540 -6,596 GRANEROS, 6,596 Tubing Pup Joint, 2 3/8in, 6,642 4.70lbs/ft, J-55, 6,678 ftKB, 6,680 ftKB 6,677 Hydraulic Fracture, 4/3/1969. Frac'd with 50,000# of 40/60 6,680 sand and 53,550 gals water. DAKOTA, 6,642-6,731, 4/3/1969 Tubing, 2 3/8in, 4.70lbs/ft, J-55, 6,695 DAKOTA, 6,695 6,680 ftKB, 6,711 ftKB 6,711 F-Nipple, 2 3/8in, 6,711 ftKB, 6,712 ftKB 6,712 Mule Shoe, 2 3/8in, 6,712 ftKB, 6,713 ftKB 6.713 6,731 6,825 6,826 Production Casing Cement, 5,866-6,837, 4/2/1969, 1st Stage: Cemented with 250 sxs 6,831 PBTD, 6,831 50/50 Class A Poz. Top of cement @ 5866' per cement top calculation. 6,836 PBTD, 6,831-6,837, 4/2/1969 Production, 4 1/2in, 4.052in, 10 ftKB, 6,837 6,837 6,840 TD, 6,840, 4/2/1969 Cement plug, 6,837-6,840, 4/2/1969 Report Printed: 8/17/2010 Page 1/1