

10. Evaluate Entrada w/DST and logs

11. Run 7", 23.0#, K55, ST/C production casing. Cement in two stages, if water flow encountered from Gallup Formation.

Stage #1 - 250 sx 50/50 Pos followed by 100 sx Class A neat.

Stage #2 - Stage collar at 3400'. 500 sx 50/50 Pos followed by 100 sx A neat.