

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED
MAR 3 1 1994
OIL CON. DIV.
DIST. 3

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

EOG (NEW MEXICO), INC. (303) 293-9999

3. Address and Telephone No.

621 17th Street, #1800, Denver, Co. 80293

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

820' FNL & 1050' FWL
NW/4 Sec. 32, T24N, R1W

5. Lease Designation and Serial No.

NM-036224

6. If Indian, Allottee or Tribe Name

N/A

7. If Unit or CA, Agreement Designation

N/A

8. Well Name and No.

CRANE FEDERAL #3

9. API Well No.

300390526200

10. Field and Pool, or Exploratory Area

SOUTH BLANCO P.C.

11. County or Parish, State

RIO ARRIBA, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☒ Other Plug back and perforate OJO
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water
(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Repair road to location.
2. MIRU contract workover rig.
3. POH laying down tubing. Run CBL log checking perfs and PBTD.
4. Set CIBP on wireline at approximately 3350.
5. Dump 3 sacks cement on bridge plug with dump bailer.
6. Pressure test 4 1/2" casing to 500 psi for 30 minutes with water.
7. If adequate cement indicated over Ojo top at 3190' then perforate the Ojo and convert to water source well. If cement is not adequate over the Ojo perforate 4 squeeze holes at about 3150' and squeeze cement with 100 sacks cement.
8. If squeezed then drill out and pressure test squeeze to 500 psi.
9. Perforate Ojo and test. Stimulate as necessary.

14. I hereby certify that the foregoing is true and correct

Signed *Shirley Mondy*

(This space for Federal or State office use)

SHIRLEY MONDY

Consultant for

Title EOG (NEW MEXICO), INC.

Date 03/17/94

Chief, Lands and Mineral Resources

MAR 30 1994

Approved by
Conditions of approval, if any:

PLACE 35X CEMENT ON BRIDGE PLUG TO COMPLY WITH REQUIREMENTS IN ORDER 2.