

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ gas ☒ other ☐
2. NAME OF OPERATOR
Caulkins Oil Company
3. ADDRESS OF OPERATOR
P.O. Box 780 Farmington, New Mexico
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 1120' From North & 890' From East
AT TOP PROD. INTERVAL: Same
AT TOTAL DEPTH: Same

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
CHANGE ZONES ☐
ABANDON* ☐
(other) ☐

SUBSEQUENT REPORT OF:

☒
☐
☐
☐
☐
☐
☐
☐
☐
☐

RECEIVED
JUN 30 1983

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

U. S. GEOLOGICAL SURVEY
FARMINGTON, N. M.

RECEIVED

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled; give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Reached TD 7610' 6-24-83

Ran 5 1/2" Casing as follows:

7610' to 6587'	(1023')	New 5 1/2"	17# ST&C K-55 Smls Casing
6587' to 1034'	(5553')	New 5 1/2"	15.5# LT&C K-55 Smls Casing
1034' to surface	(1034')	New 5 1/2"	17# LT&C K-55 Smls Casing

Stage Tools run in Casing string at 5549' and 3477'.

Cement Baskets run on Casing string at 5633' and 3562'.

(over)

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Charles Vergun TITLE Superintendent DATE 6-27-83

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

ACCEPTED FOR RECORD

JUL 08 1983

FARMINGTON DISTRICT

BY sm

*See Instructions on Reverse Side

NMOCC

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

GPO : 1981 O - 347-166

24 Centralizers run on Casing string at following points:
7568', 7529', 7486', 7443', 7408', 7366', 7323', 7280', 7238',
7197', 7154', 7111', 7069', 7035', 5591', 5508', 5468', 5427',
5385', 5346', 5303', 5262', 3519' and 3438'.

Cemented 5 1/2" Casing in three stages.

Cemented first stage thru shoe at 7610' with 412.50 Cu. Ft.
(250 sacks) 50-50 Poz, 6% Gel, 12 1/4# Gilsonite per sack
followed by 118 Cu. Ft. (100 sacks) Neat Cement.
Plug down first stage 1:10 PM 6-25-83

Cemented second stage thru stage tool set at 5549' with
412.50 Cu. Ft. (250 sacks) 50-50 Poz, 6% Gel, 12 1/4#
Gilsonite per sack followed by 118 Cu. Ft. (100 sacks)
Neat Cement. Plug down second stage 2:15 PM 6-25-83

Cemented third stage thru stage toll set at 3477' with
825 Cu. Ft. (500 sacks) 50-50 Poz, 6% Gel, 12 1/4#
Gilsonite per sack followed by 118 Cu. Ft. (100 sacks)
Neat Cement. Plug down 3:35 PM 6-25-83

Cement circulated to surface on all three stages.

Approx 2 bbls. slurry first stage.
Approx 1 bbls. slurry second stage.
Approx 5 bbls. slurry third stage.

No open hole Logs run.