

## United States Department of the Interior

## **BUREAU OF LAND MANAGEMENT**

Farmington District Office 1235 La Plata Highway Farmington, New Mexico 87401

IN REPLY REFER TO:

Attachment to Notice of

Re: Plug Back

Intention to Plug Back and Recomplete:

Well: 2E Ohio Government

## CONDITIONS OF APPROVAL

- 1. **Mike Flaniken** with the Farmington District Office is to be notified at least 24 hours before the plug back operations commence (505) 599-8907.
- 2. The following modifications to your plug back program are to be made (when applicable):
  - A: Tag CIBP at 6030' and spot a cement plug from 6030' to 5930'. (9 sks. of cement)
- B: Spot a cement plug inside the 4 1/2" casing from 5248' to 5148' plus 50 linear feet excess cement. (top of Gallup @ 5198') (14 sks. of cement)
- C: Spot a cement plug inside the 4 1/2" casing from 3188' to 3088' plus 50 linear feet excess cement. (top of Mesaverde @ 3138') (14 sks. of cement)
  - D: Depending upon the free point of the 4 1/2" casing?
- 1. If free point is below 7.0" casing shoe, in addition to the cement plug at the top of the cut off, spot a cement plug from 2008' to 1908'. Tag TOC. (7.0" @ 1958') (29 sks. of cement based on 100% excess cement for open hole)
- 2. If free point is above 7.0" casing shoe, spot a cement plug from 2008' to 1908' inside the 4 1/2" casing plus 50 linear feet excess and also the cement plug at the top of the cut off, (7.0" @ 1958') (14 sks. of cement)