<u> </u>	I-149-IND-8470			
SUNDRY NOTI (Do not use this form for propess Use "APPLICA	6. IF INDIAN, ALLOTTEE OR TRIBE NAME Navajo Tribe			
OIL CAS OTHER	7. UNIT AGREEMENT NAME Gallegos Canyon Unit			
2. NAME OF OPERATOR AMOCO Pro	8. FARM OR LEASE NAME			
Aztec Oil	Gallup Part. Area "C"			
ADDRESS OF OPERATOR AMOCO - Security Life B Aztec - 2000 First Hati Location of Well (Report location che See also space 17 below.) At surface 2040' NL, 750' EL, Sec Unit Letter H	Building, Denver, Co onal Bank Building, carly and in accordance with any	Joredo 80202	9. WELL NO. 132 10. FIELD AND FOOL, O Cha Cha Gal 11. SEC., T., R., M., OR I SURVEY OR AREA Sec. 30-T281	R WILDCAT
14. PERMIT NO.	15. ELEVATIONS (Show whether DI	E UT OR ata	1	
	571.4 KB	r, ni, en, etc.)	12. COUNTY OF PARISH	New Mexic
16. Check Appropriate of intent	propriate Box To Indicate I	Nature of Notice, Report, or C	Silver Data	
FRACTURE TREAT SHOOT OR ACIDIZE A	CLL OF ALTER CASING ULTIPLE COMPLETE BANDON* HANGE PLANS	WATER SHUT-OFF FRACTURE TREATMENT SHOOTING OR ACEDIZING (Other)	REPAIRING V ALTERING CA	SING

(Other)

(Note: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. Describe proposed on completed operations (Clearly state all pertinent details, and give pertainent dates, including estimated date of starting any nent to this work.)

**The proposed work is directionally defilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

8-5/8" surface pipe 212'. Base Ojo Alamo estimated 155'. DV tool 1652'. Perforations: 5369-77'. 4-1/2" casing in 7-7/8" hole. Inactive injection well.

Propose to plug well as follows:

- Fill hole with gel-mud. Place 10 sxs. cement (130') plug from 5377' to 5247'.
- Place 10 sxs. cement (130') plug from 1717' to 1587' 2.
- Cut 4-1/2" casing at free point (top of annular cement calculated 414') and pull same. Fill hole with gel-mud. Place 30 sxs. cement (160') plug 3. bottomed 75' below casing cut.
- Place 40 sxs. cement (134') plug from 262' to 128'
- Place 10 sxs. cement (37') plug in top of surface pipe.
- Cut off pipe at bottom of cellar, place one sack cement on top of pipe and install regulation marker.
- Clean up and level location to as near original contour as practicable. 7.

	AMOCO PRODUCTION COMPANY	^	
18.	I hereby certification the foregoing is true and correct SIGNIED	TITILIST MASS,	Dec 1 DATE 2-13-72
	(This space for Federal or State office use)		
	APPROVED BY CONDITIONS OF APPROVAL, IF ANY:	TITLE	DATE