

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I

P.O. Box 1980, Hobbs NM 88241-1980

DISTRICT II

P.O. Drawer DD, Artesia, NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

2040 Pacheco St.
Santa Fe, NM 87505

WELL API NO. 30-039-24694
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-347-39
7. Lease Name or Unit Agreement Name 009259 San Juan 31-6 Unit
8. Well No. #210
9. Pool name or Wildcat Basin Fruitland Coal 71629

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER 017654	
2. Name of Operator Phillips Petroleum Company	
3. Address of Operator 5525 Highway 64, NBU 3004, Farmington NM 87401	
4. Well Location Unit Letter <u>B</u> : <u>938</u> Feet From The <u>North</u> Line and <u>1605</u> Feet From The <u>East</u> Line Section <u>2</u> Township <u>30N</u> Range <u>6W</u> NMPM Rio Arriba County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: Set Packer & on/off tool ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plans are to try and control where gas and water separation occurs. This should solve several production problems. Details of the procedure are as follows:

1. Set wireline plugs.
2. ND WH & NU BOPs.
3. POOH w/tubing.
4. GIH w/tubing, packer and on/off tool. Set EOT @ bottom perf and packer @ TOL. Release from on/off tool. PU 5' and land tubing.
5. ND BOPs and NU WH.
6. Return well to production.

A flow back tank will be utilized instead of a pit.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Patsy Clugston TITLE Regulatory Assistant DATE 10-6-97
TYPE OR PRINT NAME Patsy Clugston TELEPHONE NO. 505-599-3454

(This space for State Use)

APPROVED BY Johnny Robinson TITLE DEPUTY OIL & GAS INSPECTOR, DIST. #3 DATE 10-8-97
CONDITIONS OF APPROVAL, IF ANY: