Form 9-881a. (Feb. 1961) 141

(SUBMIT IN TRIPLICATE)

UNITED STATES DEPARTMENT OF THE INTERIOR GEOLOGICAL SURVEY

Land Office	Sante Fe
Lease No	080466
Unit	

SUNDRY NOTICES AND REPORTS ON WELLS

NOTICE OF INTENTION TO DRILL		
1	SUBSEQUENT REPORT OF WATER SHUT-OFF	
NOTICE OF INTENTION TO CHANGE PLANS.	SUBSEQUENT REPORT OF SHOOTING OR ACIDIZING	
NOTICE OF INTENTION TO TEST WATER SHUT-OFF	SUBSEQUENT REPORT OF ALTERING CASING	
NOTICE OF INTENTION TO RE-DRILL OR REPAIR WELL	!	, .
NOTICE OF INTENTION TO SHOOT OR ACIDIZE	SUBSEQUENT REPORT OF ABANDONMENT	45
NOTICE OF INTENTION TO PULL OR ALTER CASING	SUPPLEMENTARY WELL HISTORY	
NOTICE OF INTENTION TO ABANDON WELL		
(INDICATE ABOVE BY CHECK MARK N	NATURE OF REPORT, NOTICE, OR OTHER DATA)	
	April 25,	19 62
	N line and 890 ft. from line of sec.	35
## NV Section 35 30N 12 (% Sec. and Sec. No.) (Twp.) (F	Avi KKPX Range) (Meridian)	3 46
		The same
Besin Dako ta San Jus (Field) (County or	Subdivision) (State or Territor)	VFP
	/ RLULI	1 LL
he elevation of the derrick floor above sea leve	el is 5596 ft.	4000
DET LI	MAY14	1962
DETAIL	S OF WORK	(************************************
	s, weights, and lengths of proposed casings; indicate mudding jobs, her important proposed work)	cement
Plugged and abandoned subject well 1. Mix 25 ex cement, spot the w/1000 PSI. Left S.I. 3 hrs. 2. Shot off 4-1/2" casing at		matic
Plugged and abandoned subject well 1. Mix 25 ex sement, spot the w/1000 PSI. Left S.I. 3 hre. 2. Shot off 4-1/2" casing at of stub. 3. Set 25 ex sement plug acro to 1287". 4. Set 10 ex sement plug at t	as follows: rough the and squeese off Dakota for 3164 and set 15 sx cement plug at t oss Pictured Cliff formation from 11 top of surface casing and set 4" pip	matic
Plugged and abandoned subject well 1. Mix 25 ax sement, spot the */1000 PSI. Left S.I. 3 hrs. 2. Shot off 4-1/2" casing at of stub. 3. Set 25 ax sement plug acro to 1287'. 4. Set 10 ax sement plug at t marker in 6' of cement and 4' above	as follows: rough the and squeese off Dakota for 3164 and set 15 sx cement plug at t case Pictured Cliff formation from 11 top of surface casing and set 4" pip a ground level.	matic
Plugged and abandoned subject well 1. Mix 25 ax sement, spot the w/1000 PSI. Left S.I. 3 hrs. 2. Shot off 4-1/2" casing at of stub. 3. Set 25 ax sement plug acro to 1287'. 4. Set 10 ax sement plug at t marker in 6' of cement and 4' above Nork was performed by Bedford, Inc.	as follows: rough the and squeese off Dakota for 3164 and set 15 ex oesent plug at t oss Pictured Cliff formation from 11 top of surface casing and set 4" pip o ground level. Job completed 4-10-62.	matic
Plugged and abandoned subject well 1. Mix 25 ax sement, spot the */1000 PSI. Left S.I. 3 hrs. 2. Shot off 4-1/2" casing at of stub. 3. Set 25 ax sement plug acro to 1287'. 4. Set 10 ax sement plug at t marker in 6' of cement and 4' above Nork was performed by Bedford, Inc. I understand that this plan of work must receive approval in w	as follows: rough the and squeese off Dakota for 3164 and set 15 sx cement plug at t case Pictured Cliff formation from 11 top of surface casing and set 4" pip a ground level.	matic
Plugged and abandoned subject well 1. Mix 25 ax sement, spot the w/1000 PSI. Left S.I. 3 hrs. 2. Shot off 4-1/2" casing at of stub. 3. Set 25 ax sement plug acro to 1287". 4. Set 10 ax sement plug at t marker in 6° of cement and 4° above Nork was performed by Bedford, Inc. I understand that this plan of work must receive approval in w	as follows: rough the and squeese off Dakota for 3164 and set 15 ex oesent plug at t oss Pictured Cliff formation from 11 top of surface casing and set 4" pip o ground level. Job completed 4-10-62.	matic
Plugged and abandoned subject well 1. Mix 25 ax sement, spot the w/1000 PSI. Left S.I. 3 hrs. 2. Shot off 4-1/2" casing at of stub. 3. Set 25 ax sement plug acro to 1287'. 4. Set 10 ax sement plug at t marker in 6' of cement and 4' above Nork was performed by Bedford, Inc. I understand that this plan of work must receive approval in w	as follows: rough the and squeese off Dakota for 3164 and set 15 ex oesent plug at t oss Pictured Cliff formation from 11 top of surface casing and set 4" pip o ground level. Job completed 4-10-62.	matic
Plugged and abandoned subject well 1. Mix 25 ax sement, spot the */1000 PSI. Left S.I. 3 hrs. 2. Shot off 4-1/2" casing at of stub. 3. Set 25 ax sement plug acro to 1287'. 4. Set 10 ax sement plug at t marker in 6' of cement and 4' above Nork was performed by Bedford, Inc. I understand that this plan of work must receive approval in w company COMPASS EXPLORATION, INC. ddress P. C. Box 1136	as follows: rough the and squeese off Dakota for 3164 and set 15 sx oement plug at to ose Pictured Cliff formation from 11 top of surface casing and set 4" pip of ground level. Job completed 4-10-62. Triting by the Geological Survey before operations may be comment	cop 681 ee
Plugged and abandoned subject well 1. Mix 25 ax sement, spot the */1000 PSI. Left S.I. 3 hrs. 2. Shot off 4-1/2" casing at of stab. 3. Set 25 ax cement plug acro to 1287". 4. Set 10 ax cement plug at t marker in 6° of cement and 4° above Nork was performed by Bedford, Inc. I understand that this plan of work must receive approval in w company COMPASS EXFLORATION, INC.	as follows: rough the and squeese off Dakota for 3164 and set 15 ex oesent plug at t oss Pictured Cliff formation from 11 top of surface casing and set 4" pip o ground level. Job completed 4-10-62.	cop 681 ee