



BRUCE KING
GOVERNOR
LARRY KEHOE
SECRETARY

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
AZTEC DISTRICT OFFICE

August 25, 1981

1000 RIO BRAZOS ROAD
AZTEC, NEW MEXICO 87410
(505) 334-6178

Mr. Warren E. Carr
P.O. Box 156
Bethany, Oklahoma 73008

Re: State H #1 E-2-30N-16W

Dear Mr. Carr:

The following procedure could be used to plug the referenced well without using a rig:

1. Pressure up on well and establish pumping rate into perfs.
2. Pump down a wiper plug and tag with wire line.
3. If plug is below top perforation pump twenty sacks of cement followed by wiper plug and wire line.
4. Displace plug to 1390'.
5. Perforate or cut hole in casing at 350'.
6. Circulate cement from 350' to surface inside and outside of pipe.
7. Set marker and clean location.

If you have any questions, please contact this office.

Yours truly,

A handwritten signature in cursive script, appearing to read "Frank T. Chavez".

Frank T. Chavez
District Supervisor

al