

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.
Use Min. 14-28-151-43

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

Ute Mountain Tribal

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Ute

9. WELL NO.

11

10. FIELD AND POOL OR WILDCAT

Vermis Gallup

11. SEC., T., R., M., OR BLE AND
SURVEY OR AREA

Sec. 12, T31N, R15W,

12. COUNTY OR PARISH

San Juan

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER

2. NAME OF OPERATOR
El Paso Natural Gas Products Company

3. ADDRESS OF OPERATOR
Post Office Box 1340, Farmington, New Mexico 87401

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At **2150'/S & 2000'/W, NE/4 SW/4 Section 12, T31N, R15W, NMPM**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3939' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well was plugged and abandoned on September 11, 1963 in the following manner:

- 1. Set 145' Cement Plug 1985'-2130'.**
- 2. Cut 5-1/2" OO Casing at 1308' & pulled 1198'.**
- 3. Set 130' Cement Plug 1128'-1258'.**
- 4. Set 100' Cement Plug 361'-461'.**
(Across top of Point Lookout Formation, Top at 411').
- 5. Set 50' Cement Plug across bottom of Surface Casing.**
- 6. Set 5 Sack Cement Plug at Surface with 4" Marker.**

RECEIVED

DEC 3 1963

U. S. GEOLOGICAL SURVEY
FEBRUARY 1, 1964



18. I hereby certify that the foregoing is true and correct

SIGNED BY: **JOHN J. STROJEK**

TITLE

Petroleum Engineer

(This space for Federal or State office use)

APPROVED

FEB 25 1965

JERRY W. LONG
DISTRICT ENGINEER

TITLE

DATE

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations; and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of packing of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1963-O-685229

