Form 3160-5 (June 1990)

## UNITED STATES DEPARTMENT OF THE INTERIOR RUBEAU OF LAND MANAGEMENT

FORM APPROVED Budget Bureau No. 1004-0135 Expires: March 31, 1993

DUNEA	O OF LAND MANAGEMENT	/	
SUNDRY NOTICES AND REPORTS ON WELLS  Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.			5. Lease Designation and Serial No. SF-078051
Use "APPLICATION FOR PERMIT - " for such proposals		8. If Indian, Allottee or Tribe Name	
			7. If Unit or CA, Agreement Designation
1. Type of Well Oil S Gas Well Other			
2. Name of Operator . Attention			B. Well Name and No. Neil A 8
Amoco Production Company Julie Acevedo			9. API Well No.
3. Address and Telephone No.			30 045 11058
P.O. Box 800, Denver, Colorado 80201			10. Field and Pool, or Exploratory Area
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)			Blanco Mesaverde
			11. County or Perish, State
1815' FNL, 1050' FEL, Sec. 4, T31N-R11W			San Juan, New Mexico
12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA			
TYPE OF SUBMISSION	TYPE OF ACTION		
Notice of Intent  Subsequent Report  Final Abandonment Notice	Abandonment Recompletion Plugging Back Casing Repair Altering Casing Other		Change of Plans  New Construction  Non-Routine Fracturing  Water Shut-Off  Conversion to Injection  Dispose Water  I results of multiple completion on Well Completion or a Report and Log form.
13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*  Amoco Production Company received prior approval to abandon the subject well however procedures have since been revised. Please see attached for your approval the new procedure:			
			<i>(</i> )
If you have any questions please call Julie Acevedo at 303-830-66003.			
		ECEIVE DECC 9 1392	2007 -7 F.7 1:55

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, ficticious, or fraudulent statements or representations as to any matter within its jurisdiction.

Sr. Staff Assistant

Date 12/3/92

## PXA Procedures Neil LS #8 4H-31N-11W

- 1. Check location for anchors. Install if necessary. Test anchors.
- 2. MIRUSU. Blow down well. Kill well if necessary with mudd.
- 3. POOH with 2" tbg and lay down. TIH with sawtooth collar and scraper to 7"csg shoe. RIH with 2 3/8" workstring and retainer. Set retainer at 4400'. Test casing integrity to 1000#.
- 4. Pump into open hole establishing rate and pressure. Squeeze open hole with 611 sx (100% excess) of class B cement. Pull out of retainer and spot a cement plug to 2300 with 691 sx class b cement.
- 5. Run wireline and perf at 2260'. Attempt to circulate to surface. Spot a cement plug from 2260 to 2160 inside and outside of casing.
- 6. If unable to circulate to surface perf at 1760 and again attempt to circulate to surface. Spot a cement 100' cement plug inside and outside casing from 1760' to 1660'.
- 7. Spot a cement plug inside and outside casing from 220' to surface.
- 8. NDBOP. Cut off casing and wellhead. Install PXA maker according to BLM or State requirements.
- 9. Turn over to John Schwartz for reclamation.
- 10. Rehabilitate location according to BLM and state requirements.

NEIL LS 008 1654 Location — 4H— 31N—11W SINGLE MV Orig.Completion — 4/54 Last File Update — 1/89 by DDM

