

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)

Budget Bureau No. 1004-0135
Expires August 31, 1985

3. LEASE DESIGNATION AND SERIAL NO.

Federal-91001685

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Holmberg Gas Com

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Blanco/Mesaverde

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 28 T32N-R10W

12. COUNTY OR PARISH
San Juan

13. STATE
New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

Amoco Production Company Attn: John Hampton

3. ADDRESS OF OPERATOR

P.O. Box 800, Denver, Colorado 80201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

890' FNL & 1650' FEL

14. PERMIT NO.

API.# 3004511281

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6054' RDB

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) Check Casing

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)*

Notice of intent to check for casing and repair if necessary.
See Attached:

RECEIVED
MAR 08 1990
OIL CON. DIV.
DIST. 3

If you have and questions call Cindy Burton (303) 830-5119.

THIS APPROVAL EXPIRES JUN 04 1990

18. I hereby certify that the foregoing is true and correct

SIGNED

John L. Hampton

TITLE

Sr. Staff Admin. Supv.

DATE

11/17/89

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

AMOCO

Approved

MAR 05 1990

Chief, Branch of
Mineral Resources
Farmington Resource Area

*See Instructions on Reverse Side

Holmberg Gas Com #1
Sec 28B T32N R10W

November 8, 1989

Casing Leak Repair Procedure

- 1) MIRUSU&WL,
- 2) Kill well w/ 2% KCL, NDWH, NUBOP
- 3) RIH w/ Tubing Plug(no apparent seating nipple in tubing)
- 4) Pressure Test Tubing to 1000 psi
- 5) ROH w/ Tubing Plug
- 6) TIH and Tag fill, TOH w/ Tubing
- 7) RIH w/ 7" RBP, Set at 4600'
- 8) Pull one stand, pressure test RBP to 2000 psi,
Load backside and pressure test to 750 psi to confirm
leak.
If no casing leak, repair wellhead leak and proceed to
Step 15
If leak(s) indicated, continue to Step 9
- 9) Work up hole and locate leak(s), Establish rate with
fresh water, TOH
- 10) Run CBL/GR from 4600' to surface
If is leak at top of cement, attempt to establish
circulation to surface in preparation to circulate
cement to surface. If leak in cement, or more than
100' above TOC, or if circulation cannot be established
to surface, then prepare for a spot squeeze(100 sx)
- 12) Squeeze leak(s) w/ cement
- 13) WOC for 24 hours
- 14) Drill out cement w/ bit and casing scraper
- 15) Pressure test casing to 750 psi, Swab test squeeze, If test
OK proceed to Step 15,
If test is negative, repeat steps 10 through 14
- 16) TIH w/ work string and wash to top of RBP, Retrieve
RBP, TOH
- 17) If fill, TIH w/ work string and clean to PBD, TOH
- 18) TIH w/ 2 3/8" Tubing, S-Nipple, and Saw Tooth Collar
Set at 5254'(if tubing found to leak in Step 4,
replace bad joints)
- 19) NDBOP, NUWH. Kick well around w/ N2
- 20) RDMOSU

Amoco Production Company

ENGINEERING CHART

Sheet No. _____ of _____

File _____

Appn _____

Date 11/6/89

By JAB

SUBJECT Holmberg Gas Com #1
Wellbore Diagram

Sec 28 B T32N R10W

