

Cahn Gas Com #2 Continued

8. PU tbg to 1263' & reverse out 10 sx cmt & circ. Pmp 40 sx Class G cmt 2% CaCl<sub>2</sub>. Plug from 1263' to 741'.
9. PU tbg to 777' & reverse out 2 sx cmt & circ.
10. Tag cmt @ 8791'. Pmp 85 sx Class G cmt 2% CaCl<sub>2</sub>. Plug from 879' to surf. LD tbg.
11. TIH tbg to 130'. Pmp 1.5 BBL cmt & circ to surf. TOH tbg.
12. Set cmt hose in top of csg & pmp .5 BBL cmt to surf.
13. Cut off Bradenhead. Weld on cap & PxA marker.
14. Restore location.

PxA procedure approved by Charles Gholson on location during PxA.

Please call Cindy Burton at 303-830-5119 if you have any questions.