

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.
30 045 22178

5. Indicate Type of Lease
STATE ☐ FEE ☒

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS)

1. Type of Well:
OIL WELL ☐ GAS WELL ☒ OTHER

2. Name of Operator
Amoco Production Company Attn: John Hampton

3. Address of Operator
P.O. Box 800, Denver, Colorado 80201

4. Well Location
Unit Letter N : 1110 Feet From The South Line and 1185 Feet From The West Line
Section 28 Township 32N Range 10W NMNM San Juan County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
6059' GL

7. Lease Name or Unit Agreement Name

Schneider Gas Com /B/ ^{FRT.}

8. Well No.

1

9. Pool name or Wildcat

Cedar Hill Basal Fvt. Coal

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Amoco Production Company intends to plug and abandon the subject well.
See attached for procedure:

RECEIVED
MAY 02 1990
OIL CON. DIV.
DIST. 3

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

J. Hampton

TITLE

Sr. Staff Admin. Supv. DATE 4/30/90

TYPE OR PRINT NAME

TELEPHONE NO.

(This space for State Use)

Original Signed by CHARLES GHOLSON

APPROVED BY

DEPUTY OIL & GAS INSPECTOR, DIST. #4

DATE

MAY 09 1990

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED
MAY 18 1963
OIL CONT. DIV.
DIST. 3

Original received from [illegible]

Copy of [illegible] from [illegible]

PROCEDURE
SCHNEIDER GAS COM /B/ #1

1. Check Bradenhead, casing and tubing pressures
2. MIRUSU
3. Pull rods and pump.
4. Install BOP.
5. TOH with 2 3/8" tubing.
6. Visually inspect tubing, lay down bad joints, replace with workstring if necessary.
7. Drill out CIBP at 2810' and clean out hole to PBTD (2870').
8. TIH with retainer and set at 2500'. Pump 50 sacks of class G neat cement through retainer. Stage last 3 bbl and dump 2 bbl on top of retainer. TOH
9. Spot 600' cement plugs from 2500' to surface.
10. Cut off casing, weld plate with inscribed wellname and location, and finish PxA operations according to state regulations.