

RBP @5160 - TOH with plug TIH with bailer to 4900' SWIFN. SICP=150 SITP=10 SIBHP=0 PSI Bled off press finished TIH with bailer tagged and cleaned out fill from 5238' to 5260 used 65 bbls - TOH with bailer - TIH with 1/2 mule shoe, 1 jt, sn, 167 jts, - lkanded tbg @5198 - ND BOP SU well head - RU to Swab - IFL 4500' made 25 runs, rcovered 40 bbls 4800'. SICP = 170 PSI SWIFN getting some oil in runs - trace. SICP = 170 SITP=50 SIBHP=0 bled off press - RU to swab IFL = 4800 made 8 runs recovered 10 bbls m 4500 ft. SWP DDMOSU - Wait on Swab rig . Well shutin waiting on swab rig . MIRU swab rig - made 9 runs rec 19 bbls well started to flow - put well on compressor over night. SICP=195 made 3 4uns rec 3 bbls well started to flow - flowed to tank for 4 hrs rec 6 bbl put well on line RDMOSWB Rig 10/12/92.