

## GARDNER GAS COM 1

### CONTINUED:

9. Spot 4 600' cmt plugs x 221 sx class B Neat cmt w/ 2%CA<sub>2</sub>CL<sub>2</sub> from 2469' to surface x pmp 5 BBL cmt to fill csg to surf. Pmp 5 BBL cmt into Bradenhead. Squeeze~~d~~ to 1000 psi.
10. Cut off Bradenhead, weld on cap x dry hole marker; Reclaim location.

If you have any questions please contact Cindy Burton @ 830-5119.