

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

Southland Royalty Company

3. ADDRESS OF OPERATOR

P. O. Drawer 570, Farmington, New Mexico 87499

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

790' FSL & 790' FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether OF, RT, GR, etc.)

6110' GL

5. LEASE DESIGNATION AND SERIAL NO.

SF-078040A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Childers

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Blanco Pictured Cliffs
Undesignated Fruitland

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Section 1, T31N, R11W

12. COUNTY OR PARISH

San Juan

13. STATE

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☐
☐
☒

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

Commingle

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

☐
☐
☐
☐
☐

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Southland Royalty Company hereby requests to commingle the Fruitland and Pictured Cliffs formations on the subject well as follows:

- 1) Blow down both strings of tubing and casing.
- 2) MIRU Service Unit.
- 3) NU BOPE.
- 4) POOH with 1-1/4" short string and lay down on float. Before POOH with 1-1/4" check fill on packer and clean out if necessary.
- 5) Unseat Model "R" Packer, pick up 1-1/2" tubing tag bottom, check if fill over bottom perforations.
- 6) POOH, stand back 1-1/2" tubing and blast joints.
- 7) If fill over perforations, run hydro-static bailer and clean out to 2976'.
TIH with 1-1/2", 2.7#, J-55 tubing with 1-1/2" seating nipple one joint off bottom.
- 8) Land 1-1/2" tubing at + 2900' with blast joints spaced out across Fruitland perforations.
- 9) ND BOPE, NU Wellhead.
- 10) Rig down.

RECEIVED

APR 23 1984

OIL CON. DIV.

DIST 3
4-16-84

18. I hereby certify that the foregoing is true and correct

SIGNED

D. R. Hain

TITLE

Petroleum Engineer

DATE

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

APR 18 1984

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

NMOCC